

Orbital welding controller OWC *plus*

Instruction manual



Contents

	Contents	Page 2
1.	General information	Page 3
2.	Safety guidelines	Page 3
3.	Application	Page 4
4.	Description of functions	Page 5
5.	Scope of delivery OWC plus (Original equipment-Standard)	Page 6
6.	Views of the controller	Page 7
6.1.	Right side of the controller	Page 7
6.2.	Back side of the controller	Page 8
7.	„Orbital setting software“ in the power source	Page 10
8.	Operation	Page 11
8.1.	Display – buttons and their functions	Page 11
8.2.	Welding display (main display)	Page 12
8.3.	„P-Button“, its functions and displays	Page 13
8.4.	„Enter-Button“, its functions and displays	Page 14
9.	Welding programming	Page 15
9.1.	Help function (automatic programming)	Page 15
9.2.	Test run (welding without arc)	Page 18
9.3.	Gas flow set-up and check	Page 20
9.4.	Welding process	Page 21
10.	Parameter alteration after welding	Page 22
10.1.	Percentage alteration of the power parameter	Page 22
10.2.	Parameter alteration (power, pulse time, velocity)	Page 24
10.3.	Frame parameters	Page 31
10.3.1	AVC (arc voltage control)	Page 39
10.3.2	OSC (oscillation)	Page 42
11.	Parameter increase/decrease during the welding process	Page 37
12.	Saving and percentage alteration of the welding program	Page 47
13.	Welding program information	Page 47
14.	Printing	Page 48
15.	Documentation	Page 50
16.	Other functions of the „P-Button“	Page 52
16.1.	Programming of a new welding (see chapter 9)	Page 52
16.2.	Library	Page 52
16.3.	Delete a program	Page 54
16.4.	Internal program copy	Page 54
16.5.	External program copy	Page 55
16.6.	Program copy from the external memory medium (99 memory storage space)	Page 56
16.7.	Memory formatting	Page 57
17.	Test run– Welding (see chapter 9.2.)	Page 58
18.	Gas and water test (see chapter 9.3.)	Page 58
19.	MAX/MIN – Monitoring limits	Page 58
20.	System settings	Page 61
21.	Counter	Page 63
22.	Administrator	Page 64
23.	Multifunctional remote control RC plus	Page 64
24.	Technical data	Page 66

1. General information

This instruction manual describes the features, functions, operational process and safety-related specifications of the Orbital welding controller OWC plus.

Manufacturer:

Orbital Services Australia

P.O Box 196, West Burleigh 4219

Email: sales@orbitalservices.com.au

Website: orbital-services.com.au

2. Safety guidelines

The device may only be operated by trained personnel.

Unauthorized persons shall not be allowed to open the controller. If the controller is opened by an authorized personnel (manufacturer, service and system partners), the primary cable shall be removed and voltage-free condition verified. The installation condition of the power supply is characterized by a corresponding security symbol.

3. Application

The Orbital welding controller (with Power Source T Series / Lorch Company) is widely used to perform orbital welding. This technology is applied throughout such industries, as pipeline and mechanical engineering industry, UHP media supply systems for semiconductor industry, photovoltaic industry, food industry, airline and space industry, chemical industry, as well as general engineering industry.

A new price structure and compatibility with T-Series Power Source make this technology useful for handrail manufacturers and heating engineering.

Some special features and Highlights of the OWC plus:

- a. Compatibility with tachometer controlled welding heads from other manufacturers (AMI, Orbimatic, ESAB, Dimetrics, Magnatech) as well as encoder controlled units (Cajon-Swagelok, Orbitec)
- b. Multi-range power source (100 VAC to 240 VAC)
- c. Integrated, freely-programmable buzzer (signals and error messages, button beep)
- d. Date, time, counter
- e. During the welding the wire velocity and power can be changed and saved by means of 2-level-remote control RC plus
- f. All the tests (gas, water, test procedure) can be carried out through 2-level-remote control RC plus
- g. Dokumentation option
- h. Printer interface / RS 232-Interface / Bluetooth
- i. Can-Bus-Interface for oxygen indicator PRO2 plus (digital data in second pulse)
- j. Integrated, digital flow sensor with documentation to monitor the welding gas (freely-programmable)
- k. Infinitely variable display colors (blue-white or black-white)

3. Description of functions

The Orbital welding controller is connected to the inverter power source T – Series (Lorch Company) through a digital cable (CanBus – LorchNet). This connection ensures precision orbital welding with a high quality standard industrial welding machine. This unit is inferior in non-compact orbital welding machines.

This connection provides following advantages for the user:

1. The investment in the welding machine offers an opportunity to upgrade it to „orbital“ (rent, purchase)
2. The logistic advantage in case of damage: magnetic valve defect (an inexpensive unit) leads to total loss of the orbital welding machine (replacement of the power source)

The power source is a "manual power source," and should be regarded as such. The operator can use it as usual for everyday welding.

The Orbital welding controller (Master) has two motor control cards (rotation for tachometer and encoder controlled welding heads) and one wire card for a cold wire feeder (open-frame welding heads, turn table system, tube-to-tubesheet welding heads).

All data can be digitally exchanged through the LorchNet-interface. The controller commands the power source digitally (clock rate 32 ms). These commands are being executed and sent back to the controller. Advantages for the user:


1. Any losses or irregularities (e.g. power), typical for many competitors commanding analog data, are excluded. This data transfer can be usually affected, e.g. through frequent „hissing“ of the analog voltage.
2. The controller can be connected to both components (T-Series power source). A variety of voltages are available: 180 A, 220 A, 250 A and 300 A (every one with DC and AC/DC) → all of them can perform orbital welding!

The controller selects welding programs according to the entered parameters of the pipe and welding tool. They can be stored, freely changed, copied, transferred and cancelled.

A unique feature of the controller is the simple operator guidance through easy-to-understand apt drawings and symbols familiar to welders and operators from all over the world.

3. Scope of delivery OWC *plus* (original equipment-Standard)

The scope of delivery for the controller includes: mounting sheet with holder and screws for the power source handle, a 230 V power cord, gas hose with quick-connect and a LorchNet cable between power source and controller. The power source capacity and its type can be specified by the customer in the order.




Mounted stainless steel sheet on the T 180 handle.

4. Views of the controller

6. 1. Right side

Illuminated graphic display to show all relevant information

Robust aluminium die-casting housing





Interfaces for data transfer, dokumentation, software update, etc.

Plastic foil keyboard for comfortable operation

The controller is mounted on a steel sheet and screwed with 2 M6 hex socket screws.

6. 2. Back side





Pink LorchNet cable and red gas connection hose with quick-connector between two units are easily recognizable.

When the operator releases two gas connectors, the unit can be carried comfortably on a belt over a shoulder.

7. „Orbital setting software“ in the power source

The T-Series power source has a firmware that allows to weld orbital. These settings can support data transfer between the items and provide operation, monitoring, control and documentation even with a pulse time of 50 ms.

The units of the Orbitalservice GmbH are supplied with the following settings:

1. C1 (OFF)
2. C2 (ON-gas cooled torch / welding head, OFF-water cooled)
3. C3 (ON-orbital welding, OFF-manual welding, there is no need to activate manual welding)




To alter settings in this menu, please comply with the following instructions:







1. Switch on the unit by pressing the indicated button (see picture on the left).
2. Set the potentiometer (red button in the middle of display) in the ON or OFF position.
3. Proceed forward with the right arrow button on the display (see picture in the middle). The parameters can be changed with the red potentiometer.
4. Switch off the unit.

After the re-start of the power source all alterations are already saved and activated.

8. Operation


8. 1. Display buttons and their functions



	„P-button“ is a program button. This button can be used to enter into various submenus. The button has different functions in different menus.
	„Up arrow button“ is used to proceed through the menus. The operator can navigate between the program settings and view already performed welding programs. In addition to the programming processes the button can be used to move the welding head, - direction of rotation to the right.
	„Left arrow button“ is used to proceed through the menus. The operator can navigate between the program settings and view already performed welding programs. In addition to the programming processes the button can be used to move the welding head, - direction of rotation to the left.
	„Enter-button“ is used to confirm the setting or to enter into various menus.
	„Start-button“ is used to start the welding from the controller (without remote control).
	„Stop-button“ is used to stop welding from the controller (without remote control).




8. 2. Welding display (main display)


The welding process can be started only when this display is shown. This display has a variety of stored information.



8. 3. „P-button“, its functions and displays







The „P-button“ is used to enter into different menu displays. These menus are always easy-to-understand. There is no need to translate it into different languages. The symbol with a thick, black frame can be activated by pressing the  button and the programming level will be displayed. By pressing  and  buttons the operator can navigate through the menus to the right or left.



8. 4. „Enter-button“, its functions and displays



The „Enter-button“ is used to enter into different menu displays. These menus are always easy-to-understand. There is no need to translate it into different languages. The symbol with a thick, black frame can be activated by pressing the  button and the programming level will be displayed. By pressing  and  buttons the operator can navigate through the menus to the right or left.



9. Welding programming



9.1. Help function (automatic programming)


The controller can provide first welding programs even for not very well versed users. For this purpose the software of the controller has some yearly proved basic calculations suggested by other manufacturers.

Source display:



We would like to see a demonstration program from the DIN 11850 Level 2 (typical pipe used by pharmaceutical and food industry), Ø 53 mm x 1,5 mm, with open frame weld heads OWH-114 (Ø 20 mm to Ø 114,3 mm)

Press  button




Press 



Press 




100-interval. Press 



10-interval. Press 5 times



Press 



Press  3 times



Press 



Press 



Press 



Press  5 times



Press 



The first weld head is OWH-76.

Press 




Press 



Continuous or stepped rotational velocity (stepped burner)


Press 




The welding program is ready!

There is a logic in the program:
If the wall thickness is < 2,5 mm, the program suggests a cont. rotational velocity, and for heavy wall thickness – pulse rotational velocity (stepped mode, stepped burner)


9. 2. Test run (welding without arc)




After the automatic programming the test run is suggested (welding without arc) to check all functions, e.g. correct rotation direction, cords and cables connection etc.




Press 



Press  twice




Press 




Symbol „test run“ is activated (highlighted in black).

Press 



Press 



A good visual control of the rotation (circular path with rotation degree and actually measured velocity down to the right)


Note:

During the test run the gas pre-flow and after-flow time as well as weld pool time are not used. It saves time and gas.


9.3. Gas flow set-up and check




The gas flow shall be checked before the welding process is started.
The controller is supplemented with a magnetically inductive gas flow sensor to prevent welding without gas as it can lead to defective welded joints and weld heads, especially in closed construction.



Press 



Press  4 times




Press 





Press 



The measured gas flow will be display in l/min. Now the operator can alter the settings.


Press 



Press  to return to the welding display,



The test for the water-cooled unit can be carried out in the same way.

9. 4. Welding process





Press 

Gas pre-flow time




Spark procedure
This symbol can be seen only for a short time (the quantity is not displayed to provide time for a photo)

Weld pool time




Welding process with all measured actual parameters

Downslope time




Gas after-flow time




The welding is over → Stand-by display

10. Parameter alteration after the welding


10. 1. Percentage alteration of the power parameter





The percentage alteration of the power parameter is the most common option. The operator detects the insufficient root formation after the welding. In this case more heat will be required. The operator can use the function „Percentage increase of current magnitude“ and set up a 20% increase of the whole program.



Press




Press



Hold the button  pressed until
120% appears

Press 



All parameters of the current (in all 4 sectors) increase by 20%.

10. 2. Parameter alteration (current, pulse time, velocity)



This symbol shows the following international abbreviations:

I Current
V Velocity
t Time


It is possible to enter manually into the program suggested and calculated by the controller, overwrite and alter it. Some things have been simplified to support the operator.


Task:

The operator is going to increase the pulse time by 100 in sector 4 and to reduce the high current by 4 A. This procedure will be explained in detail.


The controller has suggested a program in 4 sectors. The pipe is precisely quartered (except the 5° overlap in sector 4).

Explanatory notes of the parameter and symbols at the picture (Sector 1 / 0° to 90°)







Press 




Press 




Press 



Press 



Press 



Press 



Press 




Press 



Press 



Press 




Press 




Press 

Note:

The  button can be used to navigate forward only after the total magnitude is highlighted in black.



Press 




Press 



Press 




Press 




Press 

Note:


The pulse times have been increased by 100 ms and we enter the sector 4 to reduce the high current by 4 A!




Press 




Press 




Press 




Press 




Press 




Press 




Press 






Press 




Press 





Hold the button  or  pressed until 7 appears



Press 



Press 



Press 

All alterations are made.


Have you noticed it?

The controller has an intelligent operator guidance system.


If you want to enter into separate sectors to alter specific parameters, you will get a program support providing orbital welder-newcomers with time-saving operation and protection from programming errors.

The alteration of pulse time and velocity in sector 1 assures equal alterations of the parameters in other sectors. This operation provides uniform and synchronous weld.


In addition to the current parameters, further instruments are available to deliver and reject the target heat level.




Sector 1 before alteration (pulse times)



Sector 2 before alteration (pulse times)




Sector 1 after alteration (pulse time)



Sector 2 after alteration (pulse time)

10. 3. Frame parameters



The frame parameters are parameters required for the whole welding process. You can see it visually at the picture on the right. These parameters are given for a welding only once.

The frame parameters include the following symbols:



Gas pre-flow time (3.000 sec – 50.000 sec)



Weld pool time (1.000 sec – 50.000 sec)



Downslope time (1.000 sec – 50.000 sec)



Gas after-flow time (1.000 sec – 50.000 sec)



Pulsed current, unpulsed current (black – pulsed/ standard)







Rotation direction of the welding unit (left-right)




Pulsed rotation of the welding unit (stepped mode, stepped burner)




Cold wire addition (black – cold wire activated)








-  Activate the cold wire with  button
-  Wire delay (1.000 sec – 50.000 sec)
-  Wire return (1.000 sec – 50.000 sec)




2 x press 




Press 


The alteration of individual parameters can be made in the same order. Press the  button to enter into the submenu, - set of parameters. Here you can navigate forward with the  button. The parameters can be changed with  or . You can set a 1000-range with the  button. Repress the button  again to confirm saving and leave this menu. You can get back any time by pressing .



Alteration of gas pre-flow time



Press




Alteration of weld pool time





Press







Alteration of downslope


Press 





Alteration of gas after-flow time

Activation of pulsed current. (Standard). It can be changed by 



Rotation of the welding unit. It can be changed by 


Continuous or pulsed rotation of the welding unit.
It can be changed by 
(The automatic program settings suggest a stepped mode operation for wall thickness of > 2,5 mm)



Stepped-mode is activated




Press 




Press 




Additional wire is activated




Press 



Wire delay during the weld pool time (Hold-up time) of the weld head before rotation starts.




Press 





This frame parameter menu has the following settings: activated pulsed current (standard), pulsed rotation (stepped-mode, stepped burner) and additional filler material.

11. Parameter increase / decrease during the welding procedure





During the welding the percentage wire velocity and power can be changed and saved by means of 2-level remote control RC plus (for further information please see chapter Remote Control – RC plus).





Press 

Press  3 times




Press 


Press 



Alter




by pressing  or  then 


Press  then 




Press 


Alter

by pressing  or  then 


Press the  button to return into the main menu.



Alteration during the welding:




The current magnitude in all sectors has increased by 25%.





The wire parameters in all sectors have increased by 15%.


10.3.1 AVC (Arc Voltage Control)



Press 




Press 2 x 




Press 




Press 7x  or 1x 




Opens a additional menu with more frame parameters (tack, additional cold wire, AVC, OSC)

Press 




Press 2x 




AVC (arc voltage control)



Press 




Press 




AVC (arc voltage control) enabled


Can be changed with  and 




Press 




Changes the distance of the AVC welding electrode (equal to the arc voltage in volt)




Press 



Regulating sensitivity (time interval/traversing distance): First digit corresponds to time interval, second digit corresponds to traversing distance (stroke) per time interval




Press 




AVC retreat in mm/second: During the lowering time from less than 30A the weldinghead will be controlled retreated in mm/second.

If the chosen value is 0, the weldinghead will rest in the same position during the lowering time.





Press 





AVC height distance: Value equates to the distance of the electrode to the workpiece. This height will be automatically approached before welding. The electrode will touch the workpiece (teaching). If value is 0, Teaching will be disabled.

10.3.2 OSC (Oscillation)





Press 


Press 2x 




Press 



Press 7x  or press 1x 





Opens a additional menu with more frame parameters (tack, additional cold wire, AVC, OSC)



Press 3x 



Press 





OSC (oscillation)

Press 



Press 



OSC (oscillation) enabled


Can be changed with  and 

Press 



OSC oscillation speed: The higher the value, the faster the torch is oscillating.


Press 




OSC pendulum distance (*especially for the inal pass*): Entered value is the distance from the weld centre to the left or right side. Value will be reset to 0 if




is enabled.




Press 




Flank time: Value corresponds to the flank time in seconds at the end of every pendulum distance.




Press 




Automatic teaching (especially for middle pass): Automatic approaching weld centre depending on the OSC margin distance. For this function it is absolutely necessary to set a value for the OSC edge distance




OSC automatic teaching enabled (especially for root pass): The weld centre will be automatically approached without the dependence on the OSC edge distance.


Here for the  symbol is disabled!



Press 




OSC edge distance: Value corresponds to the distance to the taught flank in depending on


the automatic OSC teaching function  (shown in the next picture)


Enable Symbol with 

If symbol is not enabled, the entered value of the OSC edge distance will be ignored during the welding process!




Absolutely necessary for OSC edge

distance: 






Press 





OSC synchronisation: Flanks will be welded with high current and high current time, if function enabled. The distance until next flank (with OSC pendulum speed) will be welded with basic current. In this case the in advanced entered values will be ignored in the OSC flank time at welding.

12. Saving and percentage alteration of the welding program




You can save all alterations by pressing . The same is applicable to the parameters changed by .

13. Welding program information










The operator can give a name to a program or procedure and it will appear in print.




A variety of numbers, letters and symbols are available in this menu.

Please use the buttons  and  to enter the required parameter and  to navigate forward.


14. Printing



Press 





Press 



The last welding program with target and actual parameters will be printed

Press 




The target and actual parameters will be printed automatically after the welding.

15. Documentation




The controller is designed to store up to 250 welding parameter sets with relevant information. These data sets can be displayed, activated, printed, saved (PC- documentation) or deleted.




Press 





Press 



The „169“ dataset display





Press . The required dataset and its parameters (incl. target / actual values) will be printed.



Press 




Are you going to delete all documentation in the controller? If **NO**, press  If **Yes**, press 




Press 



Delete process





Press  to copy data to the external memory medium (RS 232-Dongle-Orbitalservice GmbH)

16. Other functions of „P-Button“

Thus, you have got the most important information regarding the welding procedure (assignment, alteration, printing and saving of the welding programs) and we would like to acquaint you with some additional functions of the P-button.

16. 1. Programming of a new welding (see chapter 9)

16. 2. Library




Press 




Library (99 program places)




Delete a program




Internal copy of the programs




Program copy into the external memory medium




Program copy from the external memory medium




Memory formatting



Press



If this is the required program, please press




Define the welding unit used for operation and press




If the welding unit is not suitable for this application, this warning message with a signal tone will be displayed. Press the Stop-button to acknowledge the message and choose the right welding unit.



Press



16. 3. Delete a program



Press 




If NO, press , if YES, press 





Press 

16. 4. Internal program copy



Press 



Enter the number, and press 




Press 





Press 


16. 5. External program copy




Press 





Enter the number, and press 




Press 



Enter the number, and press 




Press 





Press 


16. 6. Program copy from the external memory medium (memory capacity: 99 places)



Press 




Enter the number, and press 



Press 





Enter a weld head, and press 




This warning message will appear if the controller finds the internal description for this program. Press STOP to return, and OK to rewrite.

16. 7. Memory formatting



Plug the memory into the RS 232

interface and press 

A formatted memory can be applied for various functions. You can use it to store welding parameter data, as well as copy and save your welding programs.

Note:

To store welding programs for the PC documentation purposes is not the same as to copy programs into or from the controller memory. These two procedures have different addresses. If you are going to use a memory, you have to format it every time before starting a new procedure!


17. Test run – Welding (see chapter 9.2.)

18. Gas and water test (see chapter 9.3.)


19. MAX/MIN – Monitoring limits




Press




Press




Percentage current monitoring




Press




Min. arc voltage



Press




Max. arc voltage




Press




Percentage velocity monitoring (for Stepped-mode 50%)



Press



Freely adjustable spark current
(Recommendation: 25 A)




Press







Gas flow monitoring




Press 



Rest oxygen content before welding



Press 




Rest oxygen content during the welding


20. System settings




Press 



Press 




Date and time set-up option



Press 



Stepless contrast control




Press 



Automatic coil and uncoil of the tube packet (open-frame weld heads) 00 – no coil and uncoil



11 – Coil and uncoil is activated



Press 
Signal tone



White signal tones (button click and buzzer are deactivated)




Black signal tones (button click and buzzer are activated)

21. Counter



22. Administrator



Press 

This information area is reserved for the manufacturer and service partners. Here you can find all welding units, update your software and language files and localize errors using various integrated diagnostics and monitoring programs.

23. Multifunctional remote control RC plus



The remote control RC plus is a manageable unit with a silicon holster to protect it from any damage. The plastic foil keyboard has a robust polycarbonate case to ensure proper grip even through hard welding gloves.



24. Technical data

Mechanic:

Dimensions (LxWXH)	240 mm x 170 mm x 90 mm
Weight	2,2 kg
Degree of protection at 20 °C	IP 40

General data (electrical engineering)

Voltage	100 – 240 V, 47 – 63 Hz
Power input	60 Watt
Fuse	
Key board	6 buttons (short-stroke keys)
Display	graphic display (128 x 64 Pixel) Colors: black - white or blue - white