













To connect the Detection Relay and the Fault Relay contacts in series, connect WHITE (pin 5) to GREY (pin 8). The ORANGE (pin 4) will be connected to PURPLE (pin 9) whenever there is no Detection and no Fault while the Antenna unit is powered up. Otherwise, ORANGE (pin 4) and PURPLE (pin 9) are open contacts.

ENHANCED RELAY OUTPUT (-04I ANTENNA VERSION)



