

QD 4 SQUARE DRIVE HYDRAULIC TORQUE WRENCH MANUAL REVISION 9 2/24/2012



Bolttech-Mannings Inc. 501 Mosside Blvd. North Versailles, PA 15137 Phone: 724-872-4873 www.bolttechmannings.com 8 7 6 5 4 3 2 1

# OPERATIONS / MAINTENANCE MANUAL MODEL QD4 SQUARE DRIVE

# **Revision 8**

# **GENERAL**

All Bolttech-Mannings Hydraulic Wrenches are supplied completely assembled, ready for use. A hydraulic Power Pack is required to provide the speed and pressure that makes your Wrench System efficient and accurate.


## **CONNECTING THE SYSTEM**

The wrench head and power pack are connected by a 10,000 psi hose assembly which consists of two hoses. One hose has a female connector on each end while the other has male connectors. Connect the twin line hose to the wrench head and pump. Insure the connectors are fully engaged and screwed snugly and completely together.

# DRIVE DIRECTION CHANGE FOR SQUARE DRIVE TOOLS ONLY

(to change from loosening to tightening)


# LOOSEN




Remove the hand wheel in the drive cap which is located on the opposite side of the drive extension and pull the drive out of the tool housing. Place the drive in the desired direction, re-insert the drive cap and secure the hand wheel.

NOTE: The square drives are splined. As you push the spline part of the drive into the tool, align the ratchet and push, while slowly rotating, the square drive into position.

REVISIONS										
ZONE	REV.	DESCRIPTION	DATE APPROVE							





SOFTWARE: SOLID WORKS		DATE	NAME	R	OL	18	TE	CH		
UNLESS OTHERWISE SPECIFIED:	DRAWN					Future of B				
DIMENSIONS ARE IN INCHES	CHECKED			CUSTOMER:						
FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE	ENG APPR.									
TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	MFG APPR.			TITLE:						
MATERIAL	Q.A.									
	PROPRIETARY	PROPRIETARY AND CONFIDENTIAL								
HEAT TREAT	THE INFORMATION CO DRAWING IS THE SOLE BOLTECH ANY REPR		OLE PROPERTY OF		DWG	DWG. NO.		REV		
FINISH	OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLTTECH IS PROHIBITED			В						
	PERMISSION OF BOLFTEON IS PROPIDITED.			SCAL	E: 1:4	WEIGHT:	SHEE	T 2 OF 18		

7 6 5 4 3 2

8 7 6 5 4 3 2 1

REVISIONS										
ZONE	REV.	DESCRIPTION	DATE	APPROVED						

# **REACTION ARM**

All Bolttech-Mannings Hydraulic Wrenches are equipped with a universal reaction arm. These reaction arms are employed to absorb and counteract reaction forces created as the units operate. The reaction arm should always extend in the same direction of the square drive; however, adjustments may be made to suit your particular application.

To adjust the reaction arm, unscrew the reaction arm retaining clamp and slide the reaction arm off of the housing. Next, rotate the reaction arm to the desired orientation and slide it back onto the housing and secure the retaining clamp.

# **SETTING TORQUE**

With the system fully connected and the proper power supply available, find the desired torque conversion chart supplied for your particular tool model. Read across to the corresponding pressure. This pressure is to be set on the pump. To do so, turn on the pump, press down on the "advance" remote control button and hold, pressure will build up on the gauge. To adjust pressure, loosen the locking ring on the pressure regulator valve and turn the thumbscrew clockwise to increase pressure, counterclockwise to decrease pressure.

NOTE: When decreasing pressure, it is necessary to turn the thumb-screw to a pressure setting BELOW what is desired and gradually increase the pressure to the desired level.

Once the desired pressure is stabilized, re tighten the locking ring.

PRIOR TO BEGINNING TO TORQUE - PRESS DOWN ON REMOTE CONTROL BUTTON AND CONFIRM THE CORRECT PRESSURE HAS BEEN SET.

# **APPLYING THE TORQUE WRENCH**

Place the proper size impact socket on the square drive and secure properly with a locking ring and pin.

Place the tool and the socket on the nut making sure that the socket has fully engaged the nut and that the square drive is fully into the socket.

Make sure the reaction arm is firmly abutted against a stationary object (i.e. an adjacent nut, flange, equipment housing, etc.)

Make sure that the hoses are not placed between the reaction members.

Apply momentary pressure to the system to ensure proper tool placement.

# **SAFETY PRECAUTIONS**

Your Bolttech-Mannings torque wrench is a power tool, and as with any power tool, certain safety precautions should be observed to avoid accidents or personal injury. The following tips will assist you:

- . Do not kink the hydraulic hoses, and be sure they're clear of any possible reaction surface during operation.
- . Do not use the hoses or any hydraulic connection as a "handle".
- . All in-line links are supplied with a boot. The boot is to be used as a reaction surface. Always use a boot with a in-line link, failure to do so will cause permanent damage to the cylinder and void the manufacturer's warranty.
- . All square drive links are supplied with a reaction bar. The reaction bar is to be used as a reaction surface. Always use the reaction bar with a square drive link, failure to do so will cause permanent damage to the cylinder and void the manufacturer's warranty.
- . Be sure the reaction boot retaining clamp is fully engaged. The reaction bar or boot should be located on a solid, secure reaction point. For added safety, remain clear of the rear of the reaction bar or boot during operation. Also, when initially applying the tool, pressurize the system momentarily; if the tool tends to "ride up" or "creep", stop and re-adjust the reaction bar or boot to a more solid and secure position.
- . Always use top quality impact sockets in good condition, which are the correct size and fully engage the nut. Hidden flaws, however, remain a possibility which could cause breakage, so stay clear of sockets during operation.
- . In most cases, the tool will allow "hands-free" operation. If the tool must be held or steadied during operation, avoid handling the area around the reaction bar or boot.
- . Electric pumps should never be used in any atmosphere which could be considered potentially volatile. If there is any doubt, use an air pump.

  At Bolttech, safety is one of our primary concerns. By following these few, simple precautions, you'll be sure to obtain the most beneficial use of your Bolttech-Mannings wrench system in the safest manner possible.

SOFTWARE: SOLID WORKS		DATE	NAME	R	OL	18	TE	CH	
UNLESS OTHERWISE SPECIFIED:	DRAWN					Future of B			
DIMENSIONS ARE IN INCHES	CHECKED			CUSTOMER:					
FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE	ENG APPR.								
TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	MFG APPR.			TITLE:					
MATERIAL	Q.A.								
	PROPRIETARY	PROPRIETARY AND CONFIDENTIAL							
HEAT TREAT	THE INFORMATION DRAWING IS THE SC BOLTTECH ANY RE				DWG	DWG. NO.		REV	
FINISH	OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLTTECH IS PROHIBITED			В					
	PERMISSION OF BOLLIECH IS PROHIBITED.			SCAL	E: 1:2	WEIGHT:	SHEE	T 3 OF 18	

7 6 5 4 3

8 7 6 5 4 3 2

	REVISIONS										
ZONE	REV.	DESCRIPTION	DATE	APPROVED							

# **OPERATING THE WRENCH SYSTEM**

By depressing the remote control button, the rear of the tool will be pushed back until its reaction arm contacts its reaction member. Continue to hold down the button as the socket turns until you hear an audible "click" which will signify that the hydraulic cylinder inside the tool is fully extended and will not turn the nut any further. There will be a rapid buildup of pressure to the point of where the pressure was preset prior to applying the wrench.

IMPORTANT: This rapid buildup of pressure does not indicate that this pressure (torque) is being applied to the fastener. It only indicates that the cylinder is fully extended and can not turn the socket further until the tool is retracted to pick up the next tooth on the ratchet wheel.

Releasing the remote control button will retract the cylinder, the tool will automatically reset itself and the operator will hear an audible "click" indicating he can again push the remote control button and the socket will turn. Each time the cylinder is extended and retracted, it is called a cycle. Successive cycles are made until the tool "stalls" at the pre set pressure (torque).

NOTE: Always attempt one final cycle to insure the "stall" point has been reached.

Should the tool "lock on" after the final cycle, push down the remote control button to build pressure. While maintaining this pressure rotate the release mechanism and relieve the pump pressure. This will allow the tool to be easily removed.

# LOOSENING PROCEDURES

First, set the pump to 10,000 psi. Change the drive and reaction arm to the loosening mode and apply the tool, assuring the reaction arm abuts squarely off a solid reaction point. Press and hold the remote control button. Pressure will build up as the socket begins to turn. Cycle the wrench until the fastener is loose enough to turn by hand.

If the socket does not turn using the above procedure, it is an indication that you will require the next larger size tool to loosen the fastener.

# PREVENTIVE MAINTENANCE

Tool failure does occur. Such failure is most often in the hydraulic connectors or hoses. These items are repairable/replaceable immediately, since they are available universally. Failure of structural members of the tool are quite rare, but replacement parts are available from stock.

Special tools are required for the disassembly of the hydraulic cylinder and drive mechanism.

. <u>LUBRICATION</u>: All moving parts should periodically be coated with a good quality molybdenum disulfide grease. Under harsh environmental conditions, cleaning and lubricating should be done more frequently.

. <u>HYDRAULIC HOSES</u>: Hoses should be checked for cracks and leaks after each job. Hydraulic fittings can become plugged with dirt and should be flushed periodically.

. <u>QUICK-CONNECTS</u>: Fittings should be kept clean and not allowed to be dragged along the ground or floor, as even small particles of dirt can cause internal valves to malfunction. External leakage can be eliminated by applying a fresh coat of good quality sealant to the threads and tightening securely.

. <u>SPRINGS</u>: Springs are used for the drive pawl assembly and ratchet device. These springs should be checked twice a year and replaced, if necessary.


. <u>HYDRAULIC SEALS</u>: If the cylinder packing should require replacement because of leaks, it is recommended that all other seals and o-rings be replaced at the same time. Seal Kits are readily available.


. <u>MACHINE PARTS</u>: All components that are included on the tool should be inspected once a year to determine if there are any cracks, chips, or deformities. If so, immediate replacement is required.

. <u>CYLINDER BOLTS</u>: Periodically check to see if the cylinder bolts are properly torqued. Torque cylinder bolts in a criss-cross pattern to the following values QD2 8 ft-lbs QD4 8 ft-lbs QD8 15 ft-lbs QD14 15 ft-lbs QD30 25 ft-lbs

SOFTWARE: SOLID WORKS		DATE	NAME	B	OL	TE		E	CH
UNLESS OTHERWISE SPECIFIED:	DRAWN					Future of			
DIMENSIONS ARE IN INCHES	CHECKED			CUSTOMER:					
FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE	ENG APPR.								
TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	MFG APPR.			TITLE:					
MATERIAL	Q.A.								
		PROPRIETARY AND CONFIDENTIAL			DIMO	NG NO			551
HEAT TREAT	EAT TREAT THE INFORMATION CON DRAWING IS THE SOLE P BOILTFCH ANY REPORT		RTY OF	SIZE	DWG	. NO.			REV
FINISH	OR AS A WHOLE	OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLTTECH IS PROHIBITED.							
				SCALE	E: 1:2	WEIGHT:	SH	HEET	4 OF 18

7 6 5





# REVISIONS DESCRIPTION DATE APPROVED **QD4 HOUSING BUSHING & BOSS BUSHING ASSEMBLY** USE LOCTITE 420 (CLEAR) 14)HOUSING /HOUSING BUSHING (17) USE LOCTITE 420 (CLEAR) USE LOCTITE 420 (CLEAR) MAKE SURE BOSS BUSHING (87) IS INSERTED INTO HOUSING (14) AS SHOWN BELOW WITH FLAT AREA FACING UP. BOSS BUSHING(87 = USE LUBRICATION IN THIS AREA HOUSING BUSHING (17 ASSEMBLY INSTRUCTIONS SOFTWARE: SOLID WORKS INSERT HOUSING BUSHINGS (17) FROM THE INSIDE OF THE HOUSING (14) WITH THE BUSHING FACING UNLESS OTHERWISE SPECIFIED: DRAWN CUSTOMER: DIMENSIONS ARE IN INCHES FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005 THE DIRECTION SHOWN. CHECKED \*\* NOTE: HOUSING BUSHING MUST BE FULLY SEATED ENG APPR TITLE: IN THE HOUSING. MFG APPR. MATERIAL

8 7 6 5 7 4 3 2

USE LOCTITE # 420 TO GLUE HOUSING BUSHINGS(17) TO HOUSING(14).

LUBRICATE PARTS AS SHOWN.

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
BOLTTECH. ANY REPRODUCTION IN PART

OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLTTECH IS PROHIBITED

HEAT TREAT

SIZE DWG. NO.


SCALE: 1:4 WEIGHT:


REV

SHEET 7 OF 18

REVISIONS







2


# **ASSEMBLY INSTRUCTIONS**

8

- INSERT SWIVEL POST 0-RINGS (ITEM 52A) INTO SWIVEL BODY (ITEM 50) AS SHOWN IN SECTION A-A.
- SLIDE SWIVEL ARM O-RINGS (ITEM 52B) OVER SWIVEL BODY AS SHOWN IN SECTION A-A
- SLIDE SWIVELS (ITEM 51) OVER SWIVEL BODY AND SECURE WITH SWIVEL SNAP RINGS (ITEM 55) AS SHOWN IN SECTION A-A.

NOTE: USING A PIECE OF WIRE, MAKE SURE PORT HOLES ARE CLEAR OF DEBRIS.

ALL O-RINGS COME IN THE SWIVEL SEAL KIT





1

SOFTWARE: SOLID WORKS		DATE	NAME	B		TE	₹TE	CH
UNLESS OTHERWISE SPECIFIED:	DRAWN					Future of		
DIMENSIONS ARE IN INCHES	CHECKED			CUSTO	OMER:			
FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE	ENG APPR.							
TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	MFG APPR.			TITLE:				
MATERIAL	Q.A.							
	PROPRIET	TARY AND CONFID	FNTIAI					
HEAT TREAT	THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BOLTITECH. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN			B	-   51101 1101			REV
FINISH				D				
	PERIVISSION	PERMISSION OF BOLTTECH IS PROHIBITED.			E: 1:2	WEIGHT:	SHE	ET 8 OF 18

**QD4 FITTING ASSEMBLY** 

REVISIONS										
ZONE	REV.	DESCRIPTION	DATE	APPROVED						





**BEFORE ASSEMBLY** 

AFTER ASSEMBLY


# HIGH PRESSURE (MALE-END) HYDRAULIC CONNECTOR ASSEMBLY 2HM

## ASSEMBLY INSTRUCTIONS

- 1. THREAD MALE QUICK CONNECT (ITEM 56) INTO NIPPLE (ITEM 57)
- THREAD ASSEMBLED ITEMS 56 & 57 INTO HYDRAULIC SUB-ASSEMBLY 1H.

# NOTE:

(THE USE OF SEALING PIPE TAPE ON THREADED PORTIONS OF FITTING IS RECOMMENDED TO ASSURE A PROPER SEAL)



**BEFORE ASSEMBLY** 

AFTER ASSEMBLY

# LOW PRESSURE (FEMALE-END) HYDRAULIC CONNECTOR ASSEMBLY 2HF


## ASSEMBLY INSTRUCTIONS

1. THREAD FEMALE QUICK CONNECT (ITEM 54) INTO HYDRAULIC SUB-ASSEMBLY 1H.

## NOTE:


(THE USE OF SEALING PIPE TAPE ON THREADED PORTIONS OF FITTING IS RECOMMENDED TO ASSURE A PROPER SEAL)


SOFTWARE: SOLID WORKS		DATE	NAME	R		TE	TF	CH		
UNLESS OTHERWISE SPECIFIED:	DRAWN					Future of				
DIMENSIONS ARE IN INCHES	CHECKED			CUSTOMER:						
FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE	ENG APPR.									
TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	MFG APPR.			TITLE:						
MATERIAL	Q.A.									
		PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BOLITECH. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLITECH IS PROHIBITED.			DIVIC	NO		RFV		
HEAT TREAT	DRAWING IS THE				SIZE DWG. NO.					
FINISH	OR AS A WHOLE				<b>U</b>					
	FERNISSION OF B				E: 1:2	WEIGHT:	SHEE	T 9 OF 18		



**QD4 2ND PAWL ASSEMBLY** 

	REVISIONS											
ZONE	REV.	DESCRIPTION	DATE	APPROVED								






#### ASSEMBLY INSTRUCTIONS

- 1. INSERT 2ND PAWL EXTENSION SPRING (ITEM 69) AS SHOWN THEN SLIDE 2ND PAWL ROLL PIN (ITEM 68) INTO PLACE.
- 2. INSERT 2ND PAWL DOWL PIN (ITEM 98) THROUGH 2ND PAWL EXTENSION SPRING. PLACE 2ND PAWL ROLL PIN INTO SLOT PROVIDED IN HOUSING THEN PULL ASSEMBLED 2ND PAWL DOWN INTO POCKET.
- 3. INSERT 2ND PAWL AXLES (ITEMS 67) INTO HOUSING AND INTO 2ND PAWL ASSEMBLY. ALIGN HOLE IN HOUSING WITH THREADED HOLE IN 2ND PAWL ASSEMBLY. THREAD 2ND PAWL SET SCREWS (ITEMS 70) INTO THREADED HOLE IN 2ND PAWL. TIGHTEN 2ND PAWL SET SCREWS WITH ALLEN WRENCH.

NOTE: A NON-PERMANENT THREAD SEIZING COMPOUND SUCH AS (LOCTITE 222 THREAD LOCKER) SHOULD BE USED TO PREVENT 2ND PAWL SET SCREWS FROM COMING LOOSE.

SOFTWARE: SOLID WORKS		DATE	NAME	B	OL		ΓE	CH	
UNLESS OTHERWISE SPECIFIED:	DRAWN				_	Future of Bolt			
DIMENSIONS ARE IN INCHES	CHECKED			CUSTOMER:					
FRACTIONAL +/- 1/32" ANGULAR: +/- 1/2 DEGREE	ENG APPR.								
TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	MFG APPR.			TITLE:					
MATERIAL	Q.A.								
	PROPRIETARY	PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BOILTECH ANY REPRODUCTION IN PART			51116				
HEAT TREAT	DRAWING IS THE				SIZE DWG. NO.			REV	
FINISH	OR AS A WHOLE WITHOUT THE WRITTEN		ט						
	PERMISSION OF BOLTTECH IS PROHIBITED.			SCAL	E: 1:2	WEIGHT:	SHEE	T 11 OF 18	


8 7 6 5 4



REVISIONS

# **QD4 ENGAGEMENT BOLT ATTACHMENT**

REVISIONS											
ZONE	REV.	DESCRIPTION	DATE	APPROVED							






FIGURE 3



## **ASSEMBLY INSTRUCTIONS:**

8

1. ALIGN THE CONNECTING ROD AND THE END OF THE PISTON SO THEY SLIDE TOGETHER SMOOTHLY (SHOWN IN FIGURE 2).

\*\*NOTE: MAKE SURE BOTH THE PISTON END AND THE CONNECTING ROD ARE LUBRICATED BEFORE ASSEMBLING.

2. WITH THE HOLES LINED UP, THREAD THE ENGAGEMENT BOLT(86) UNTIL IT BOTTOMS OUT ON THE FLAT SURFACE OF THE CONNECTING ROD (SHOWN IN FIGURE 3).

	SOFTWARE: SOLID WORKS		DATE	NAME	B	OL	TS	ΓE	CH	
	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES FRACTIONAL +/- 1/32* ANGULAR: +/- 1/2 DEGREE TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005	DRAWN					Future of Bolt			
		CHECKED			CUSTOMER:					
		ENG APPR.								
		MFG APPR.			TITLE:					
	MATERIAL	Q.A.								
		PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BOLITECH. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLITECH IS PROHIBITED.			SIZE DWG. NO. RFV					
	HEAT TREAT				R	SIZE DWG. NO.				
	FINISH				D					
					SCAL	E: 1:2	WEIGHT:	SHEE	T 13 OF 18	3

8 7 6 5 4 3 2

DESCRIPTION DATE APPROVED **QD4 HOUSING/CYLINDER ASSEMBLY** FINAL INSTALLATION TAPER BOLT (27) ALIGN CYLINDER(4) AND HOUSING(14) HOLES.
 TIGHTEN TAPERED BOLTS(27) IN A CRISS CROSS PATTERN TO 8 ft-lb. ASSEMBLY INSTRUCTIONS: SOFTWARE: SOLID WORKS UNLESS OTHERWISE SPECIFIED: DRAWN 1. FULLY EXTEND PISTON(1). DIMENSIONS ARE IN INCHES FRACTIONAL +/- 1/32\* ANGULAR: +/- 1/2 DEGREE TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005 CUSTOMER: CHECKED 2. FULLY RETRACT DRIVE PLATES(18,19). ENG APPR. LUBRICATE SPHERICAL BALL ON CONNECTING ROD(85).
ATTACH ONE END OF CONNECTING ROD(85) TO DRIVE PLATE(18 OR 19) TITLE: MFG APPR. USING DRIVE PLATE PIN(26). PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
BOLTTECH. ANY REPRODUCTION IN PART SECURE DRIVE PLATE PIN(26) WITH A SNAP RING(23) ON EACH SIDE. SIZE DWG. NO. REV HEAT TREAT OR AS A WHOLE WITHOUT THE WRITTEN

3

SCALE: 1:4 WEIGHT: SHEET 14 OF 18

PERMISSION OF BOLTTECH IS PROHIBITED


DESCRIPTION DATE APPROVED **QD4 REACTION BAR ASSEMBLY** REACTION BAR (60) REACTION BAR CLAMP 95 O-RING REACTION BAR CLAMP (31) **BEFORE ASSEMBLY** AFTER ASSEMBLY ASSEMBLY INSTRUCTIONS SLIDE REACTION BAR(60) OVER CYLINDER AS SHOWN.
 PLACE REACTION BAR CLAMP O-RING (93) OVER THREADED PORTION OF THE REACTION BAR CLAMP.
 THREAD REACTION BAR CLAMP (31) ONTO CYLINDER END CAP. SOFTWARE: SOLID WORKS UNLESS OTHERWISE SPECIFIED: DRAWN DIMENSIONS ARE IN INCHES FRACTIONAL +/- 1/32\* ANGULAR: +/- 1/2 DEGREE TWO PLACE DECIMAL +/- 0.01 THREE PLACE DECIMAL +/- 0.005 CUSTOMER: CHECKED ENG APPR. TITLE: MFG APPR. MATERIAL PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
BOLTTECH. ANY REPRODUCTION IN PART SIZE DWG. NO. REV HEAT TREAT


OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLTTECH IS PROHIBITED

3

SCALE: 1:2 WEIGHT:

SHEET 15 OF 18





5 3 2 1 ITEM # PART NAME PART# QTY. REVISIONS PISTON QD403E 1 DESCRIPTION ZONE REV. DATE APPROVED CYLINDER QD401 1 4 PISTON ROD BUSHING QD417 6 1 8 CYLINDER END CAP QD402B 1 14 HOUSING QD4SQDR11 D HOUSING BUSHING QD4SQDR08 17 2 18,19 DRIVE PLATE (R/L) QD4SQDR04 2 PAWL SPRING C062-L2-S17 20 1 21 PAWL QD4SQDR03 QD4SQDR02 22 RATCHET WHEEL 1 23 DRIVE PLATE PIN SNAP RING WS-53N 2 QD406E 24 DRIVE PLATE PIN 1 27 TAPER BOLT QD408 4 31 REACTION BAR CLAMP QD4RB01 40 SQUARE DRIVE QD4SQDR05 41 DRIVE CAP QD4SQDR06-NEW 1 42 THUMB WHEEL QD4SQDR07-1 1 49 QD4 SEAL KIT QD4 SEAL KIT 1 SWIVEL POST SW13BLK 52A **BODY O-RING** SW3X-6N 3 52B STEM O-RING SW3X-5N 4 50 SWIVEL BODY SW3BLK-1 1 51 SWIVEL SIDES SW3BLK-2A 2 52 SWIVEL POST RETAINING RING WS-50N 1 55 SWIVEL RETAINING RING WS-62N 2 FEMALE QUICK CONNECT 54 SW04N 1 SW05N 56 MALE QUICK CONNECT 58 SWIVEL BODY CAP SCREWS M4X10MMLHCSN 5 58 SWIVEL BODY CAP SCREW M4X8MMLHCSN 1 SWIVEL BASE O-RINGS 59 005-9250N 2 57 1/4" X 1/4" NPT ADAPTER 1/4 NPTADAPTER 60 REACTION BAR QD4RB07 1 66 2ND PAWL QD411 1 2ND PAWL AXLE QD412 67 2 1/16X3/8RPN 2ND PAWL ROLL PIN 68 1 98 2ND PAWL DOWEL PIN 1/16X1/2DPN 1 69 2ND PAWL EXTENSION SPRING E01200180380MN 6/32X3/16SSN 70 2ND PAWL SET SCREW 2 QD4CR 85 CONNECTING ROD 86 ENGAGEMENT BOLT 10-24X3/8SHCS 1 87 **BOSS BUSHING** QD4BB 1 PISTON CONE QD4-T04 90 1 SOFTWARE: SOLID WORKS BOLTSTEC QD4-T01 CYLINDER END CAP WRENCH 81 1 UNLESS OTHERWISE SPECIFIED: DRAWN ROD BUSHING WRENCH QD4-T02 80 1 CUSTOMER: DIMENSIONS ARE IN INCHES CHECKED FRACTIONAL +/- 1/32" CYLINDER END CAP WRENCH SCREW QD4-T01WS 93 3 ENG APPR. ANGULAR: +/- 1/2 DEGREE TWO PLACE DECIMAL +/- 0.01 TITLE: ROD BUSHING WRENCH SET SCREW QD4-T02WS 3 94 MFG APPR. THREE PLACE DECIMAL +/- 0.005 95 REACTION BAR CLAMP O-RING 9452K86 MATERIAL THUMB WHEEL O-RING 70BUNA109N 96 1 PROPRIETARY AND CONFIDENTIAL SIZE DWG. NO. REV THE INFORMATION CONTAINED IN THE DRAWING IS THE SOLE PROPERTY OF 97 NAME PLATE QD4-SNPN 2 HEAT TREAT BOLTTECH. ANY REPRODUCTION IN PART CYLINDER END CAP WRENCH HEAD QD4-ECH 83 FINISH OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BOLTTECH IS PROHIBITED ROD BUSHING WRENCH HEAD QD4-RBH 84 1 SCALE: 1:4 WEIGHT: SHEET 18 OF 18

6

5

3

2