



Microtronix
Access 1000 & 4000
Synchronous/HDLC Server
Quick Start Guide 1.1.2




Table of Contents

| | |
|---|-----------|
| 1 Overview..... | 3 |
| 1.1 Access Synchronous Server models..... | 3 |
| 1.2 WAN interface..... | 4 |
| 1.3 Console interface..... | 4 |
| 1.4 Network (Ethernet) interface..... | 4 |
| 1.5 USB interface..... | 4 |
| 2 Package Check List..... | 5 |
| 3 Quick Start Guide..... | 6 |
| 3.1 Installation..... | 6 |
| 3.2 Console/WAN Port..... | 6 |
| 3.2.1 U-Boot Command Access..... | 6 |
| 3.2.2 Setting Default IP Parameters..... | 6 |
| 3.2.3 Emergency IP Address Recovery..... | 7 |
| 3.2.4 System Maintenance..... | 7 |
| 3.3 Configuration Web Interface..... | 8 |
| 3.4 IP Network Configuration..... | 8 |
| 3.4.1 Verifying IP Network..... | 8 |
| 3.4.2 Monitoring IP Network..... | 9 |
| 3.5 Synchronous Server Configuration..... | 10 |
| 3.5.1 Synchronous HDLC Settings..... | 10 |
| 3.5.2 Network Settings..... | 10 |
| 3.5.3 Update and Start the Server..... | 10 |
| 3.5.4 Verify Synchronous Server Connection..... | 10 |
| 3.5.5 Synchronous Interface Monitor..... | 10 |
| 4 Cables..... | 12 |
| 4.1 Synchronous Cables – WAN interface..... | 12 |
| 4.1.1 Connecting to a DCE device..... | 12 |
| 4.1.2 Connecting to a DTE device..... | 12 |
| 5 Encapsulation Message Formats..... | 13 |
| 5.1 MBIT (2-byte count field)..... | 13 |
| 5.2 RFC1006 (ISO TP)..... | 13 |
| 6 Contact Microtronix..... | 14 |

1 Overview

The Microtronix **Access Synchronous Server** provides conversion between a synchronous interfaces and a TCP/IP or UDP/IP socket.

A web interface allows for configuration and monitoring from any Internet browser, and telnet/SSH servers allow for connecting to the command line interface for additional management.

1.1 Access Synchronous Server models

The following table shows the available interfaces and connector type of each Access model.

| Model | RJ45 Ethernet | DB25F WAN | USB host port | Power connector |
|-------------|------------------|--------------|------------------|--------------------|
| 1000-N00 | 1 | 1 | 1 | -48VDC cable |
| 4002-N00 | 1 | 2 | 1 | -48VDC cable |
| 4002-N00-RM | 1 | 2 | 1 | -48VDC cable |

The following pictures of the rear plate of each model illustrate the interfaces and connectors.



Model 1000-N00



Model 4002-N00



Model 4002-N40-RM

The model name and serial number are printed on the label located on the bottom of the unit. The following sections describe the each attributes and function of each interface type.

1.2 WAN interface

WAN interfaces support RS232/V.24 with speeds up to 128 Kbps, and V.35, X.21, RS530, RS449/V.36 interface types with speeds up to 10 Mbps, in a standard DB25F DCE connector.

The 1000 model has one WAN interface that doubles as the boot console, and the 4002 model has two WAN interfaces with one that doubles as the Console port. See the notes under *Console interface* below.

1.3 Console interface

The Console/WAN port may be used for:

- Synchronous Server
- System console port for configuration and monitoring

In addition, the Console port serves as the console for the boot program and operates in RS232 asynchronous mode during boot up. The boot command line interface may be invoked for system management and emergency IP address recovery by entering a password during a 10 second interval after power up.

The 4002 model has a DB25F Console/WAN interface that supports all interface types.

1.4 Network (Ethernet) interface

The RJ45 NETWORK interface is 10/100 Ethernet with full auto-detection, supporting a rich set of standard IP protocols.

1.5 USB interface

The USB 1.1 type A host port supports USB flash drives for storing and moving files.

2 Package Check List

Check that the Access model received matches the order by comparing to the model number printed on the label on the bottom of the unit.

Check that the package shipped contains the following items.

- Access unit as above
- 100/240 VAC adapter with AC power cord or - 48VDC power cord
- DB9F-DB25M Console Cable
- RJ45 Ethernet patch cable (blue)
- DB25MF straight through RS232 WAN cable

The following optional items are available through special order, and may be included:

- Additional WAN or sync cable(s) – refer to the Cables section for part numbers
- USB flash drive
- 19" 1U Rack mount kit

3 Quick Start Guide

Configuration of the Access will require a PC or laptop with any standard Internet browser like Internet Explorer or Mozilla Firefox. Optionally, a serial COM port (or USB serial adapter) on the PC with a terminal emulator application may be used to connect to the Console/WAN interface.

3.1 Installation

- 1) The Access may be placed on a shelf in a rack, or mounted using a rack mount kit.
- 2) Connect to the IP network through the RJ45 10/100 Network port.
- 3) Optional: Connect the Console/WAN port to the PC using the Console Cable. Refer to the "Console/WAN Port" section below for instructions.
- 4) Connect DC power adapter and AC power cord (or attach the -48VDC power cord)
- 5) Wait 20 seconds for the boot process to complete. The RUN led will start to blink.

3.2 Console/WAN Port

The Console/WAN port offers system control access during the boot-up process. Boot messages will be displayed if a PC COM port is connected using the Console Cable, and a terminal emulator like "putty" or "HyperTerminal" is set for 9600-N-8-1.

3.2.1 U-Boot Command Access

After power up, there is a 10 second delay that allows U-Boot command access:

Autoboot in 10 seconds (Enter password to stop)...

if the password "foad" is typed while the message is displayed, the U-Boot prompt "A4K:>" will indicate command readiness.

3.2.2 Setting Default IP Parameters

The default IP network parameters may be modified or added here as an alternative to the configuration via the web interface. Enter the following commands to change the default IP address, netmask, default gateway (if needed), and optionally a new system "hostname"

```
set ipaddr 10.1.1.240
set netmask 255.255.255.0
set gatewayip 10.1.1.1
set hostname MYNAME
save
boot
```

These defaults will remain in effect until again changed again in U-Boot, or explicitly changed via the **Ethernet** configuration page in the web interface.

3.2.3 Emergency IP Address Recovery

The u-boot console may be used to recover a forgotten IP address. While in the U-Boot console, the default IP address and other parameters may be displayed:

```
print ipaddr
print netmask
print gatewayip
```

If the default values are not in current effect, they may override the system-defined values temporarily by setting new default values (if desired) and entering the U-Boot commands:

```
set ipaddr 10.1.1.240
set netmask 255.255.255.0
set gatewayip 10.1.1.1
set runlevel 2
save
boot
```

When the system starts up, it will be using the default IP address information, and should be reachable on that network. Browse into the web interface and access the Ethernet page to view the “forgotten” values. Restart the system to get the U-Boot console, and reset run level:

```
set runlevel
save
boot
```

The system will restart with the system-defined values.

3.2.4 System Maintenance

The u-boot console may also be used in conjunction with Microtronix support for applying firmware updates, and emergency IP address recovery.

To apply firmware updates:

- 1) Obtain one or both of the kernel image (ulimage) and filesystem image (jffs2.img) files from Microtronix
- 2) Start a tftpd server on the PC or an available file server
- 3) Place the file(s) in the tftpd default directory on the PC or server
- 4) Enter the PC or server IP address (example 10.1.1.200) using the u-boot commands:

```
set serverip 10.1.1.200
save
```

- 5) Load the new kernel image:

```
run updatekernel
```

- 6) Load the new filesystem image:

```
run updatejffs2
```

- 7) Start the system by re-applying power or typing the “boot” command.

3.3 Configuration Web Interface

The default IP address of the Access is **10.1.1.240**. The PC used to access the web interface must be configured (temporarily) for an address in the same subnet, for example, 10.1.1.200. Connect the PC to the same LAN, or connect directly to the Access.

Open the web browser on the PC, and enter <http://10.1.1.240> in the URL field. When prompted by a popup window, login using default user name: **admin**, and password: **admin**.

The home page will be displayed with the main menu down the left hand side. The Access can now be configured by selecting the main menu items. Each page has a **Help** button in the upper right corner for viewing additional information specific to the current page.

3.4 IP Network Configuration

To create or modify the IP network parameters different than the default values defined in U-Boot, obtain the new IP address, network mask, and default gateway values. Follow this procedure only if you don't want the default values to be used in the running system.

- 1) From the main menu **System** section, select **Ethernet** to display the configuration form.
- 2) Click on the Select button in the Ethernet Interfaces table corresponding to "eth0".
- 3) Enter the new IP address and network mask.
- 4) Click the **Apply** button for the changes to be saved and to take affect.
- 5) Enter the new Default Gateway IP address, if needed.

Connect the Network port to the new network, if not already. Since the IP connection may be lost due to the change, the new address may need to be entered in the browser. The Ethernet configuration page displays the current status of the Ethernet interface.

For more information on additional network configuration, click the **Help** button on the page.

3.4.1 Verifying IP Network

Use ping from another station on the IP network to verify the Access is reachable. Sometimes ARP cache tables are obsolete and need refreshing after an IP change.

The LAN led on the front panel or rear RJ45 connector led will blink when there is activity on the Ethernet port.

If the PC used for configuration is still able to reach the Access, use telnet or ssh to connect to the command line interface. If the unit has been pre-configured for console access on the Console port, you may use a terminal emulator to connect a PC COM port to the console using 9600-N-8-1. Login using user name "root" and password "f0adA" (0=zero).

Enter the command "ifconfig eth0" to view the status and statistics of the Ethernet interface.

Use ping to test the connection to the default gateway or another station on the IP network. Enter the command "ping a.b.c.d", where a.b.c.d is the IP address in dotted notation.

To test the connectivity to a remote IP host that will be connecting to or receiving connections from the Access, use ping to verify reachability.

3.4.2 Monitoring IP Network

Sometimes tracing an the IP interface may be necessary to determine a problem. The standard tcpdump utility is provided for this purpose. To run the tcpdump utility, make a telnet connection from a PC to connect to the Access command line interface. Respond to the login request with the default username "root" and password "f0adA" (0=zero). At the "#" prompt, enter the "tcpdump" command. It can be entered with a number of command line options. Use the "-h" option to see a list of all available options. The normal syntax is:

```
tcpdump -i INTERFACE -w OUTPUT_FILE EXPRESSION
```

To stop tcpdump, type control-C (Ctrl+C). The file can be FTP'd to the PC for display and analysis using Wireshark (Ethereal).

For example, to monitor TCP port 102 on the Ethernet interface, and record the output into a file:

```
tcpdump -i eth0 -w /tmp/tcpdump.pcap tcp port 102
```

The other possible interface is the loopback interface sometimes used for internal connections:

```
-i lo
```

For extended monitoring, the output file may also be written to a USB-mounted flash drive (formatted VFAT-32) by using the path:

```
-w /mnt/usb1/tcpdump.pcap
```

When the file is completed, the drive may be removed safely by entering the command:

```
umount /mnt/usb1/
```

Other expressions may be used like a remote IP address:

```
ip host 10.1.1.24
```

Care must be taken to **NOT** use an expression that would monitor the initiating telnet session.

3.5 Synchronous Server Configuration

WAN interfaces may be configured for raw synchronous HDLC operation by configuring it as a Synchronous Server. Ensure that the Terminal server or X.25 Gateway operation is disabled for the selected port by de-selecting the **Enabled** button on the **Serial-TCP** or **HDLC Physical Layer** page.

To configure a port for synchronous service, select **HDLC -TCP** from the main menu **Synchronous Server** section to display the configuration form.

3.5.1 Synchronous HDLC Settings

- 1) Select the **Local interface name** from the drop-down list.
- 2) Configure the settings to match the attached device.
- 3) If the device asserts a DTR signal, select **DTR detection**. This also controls TCP connectivity.
- 4) Click the **Enabled** checkbox.

3.5.2 Network Settings

- 5) Select the Encapsulation method from the drop-down list. RAW does not preserve frame boundaries across a TCP/IP interface. MBIT and RFC1006 will preserve frame boundaries when transmitting over a TCP/IP interface.
- 6) Select the protocol, TCP or UDP, to create an IP socket.
- 7) Select the port number on which a listen is posted for remote clients, or to which a connection is to be initiated towards a remote server.
- 8) Enter the remote IP address to which the connection will be made, or enter 0.0.0.0 for a TCP listen to be posted.

3.5.3 Update and Start the Server

- 9) Check the **Start / Restart Synchronous Server** box for changes to become active.
- 10) Click the **Apply** button to save changes and (re)start the server if requested.

For additional information, click the [Help](#) button on the page.

3.5.4 Verify Synchronous Server Connection

Click on the **Status** and **Control & Log** items in the **Synchronous Server** main menu section. Refer to the [Help](#) pages for details.

3.5.5 Synchronous Interface Monitor

Sometimes tracing a synchronous interface may be necessary to determine a problem. To run the monitor, make a telnet connection from a PC to connect to the Access command line interface. Respond to the login request with the default username “root” and password “f0adA” (0=zero). At the “#” prompt, enter the command:

```
hdlctrace -a hd1c0
```

Assuming that the correct cable is properly connected, and there is no transmitted data (out), then there must be a configuration problem.

If there is transmitted data but no received data (in), then there is likely a problem with the HDLC clock

configuration. Only one side of the interface can be configured to source the clock, and the other side must be configured to receive it. Chances are that the transmitter of the attached device is not receiving a clock signal.

If there is both transmitted and received data but there is still a problem, then the data itself needs to be analyzed.

Analysis beyond this is out of scope for this document. The displayed data may be captured and forwarded to Microtronix Support for analysis.

4 Cables

4.1 Synchronous Cables – WAN interface

When configured for sync, the DB25F WAN ports have an RS530 DCE pin configuration (compatible with ISO 2110). RS232 is a subset of RS530, so a WAN port has a standard RS232 pin assignment when configured for RS232 (V.24).

4.1.1 Connecting to a DCE device

The following cables are used when connecting to DCE device (like a modem) with a female connector that is supplying clocking on the DCE transmit and receive clock pins.

| Crossover cable part numbers | |
|------------------------------|---|
| W4025-V24-DTE | DB25M-DB25M RS232 /V.24 crossover cable |
| W4025-V35-DTE | DB25M-M34M V.35 crossover cable |
| W4025-X21-DTE | DB25M-DB15M X.21 crossover cable |
| W4025-RS449-DTE | DB25M-DB37M RS449/V.36 crossover cable |
| W4025-RS530-DTE | DB25M-DB25M RS530 crossover cable |

4.1.2 Connecting to a DTE device

The following cables are used when connecting to DTE device with a male connector that expects to receive clocking on the DCE transmit and receive clock pins. If replacing a modem, avoid any modem handshake issues by configuring the device's interface for "leased line" or "permanent modem" type connection.

| Straight through cable part numbers | | |
|-------------------------------------|-------------|-----------------------------------|
| 811-SC6MF | DB25MF | RS232/V.24 straight through cable |
| W4025-V35-DCE | DB25M-M34F | V.35 straight through cable |
| W4025-X21-DCE | DB25M-DB15F | X.21 straight through cable |
| W4025-RS449-DCE | DB25M-DB37F | RS449/V.36 straight through cable |
| W4025-RS530-DCE | DB25M-DB25F | RS530 straight through cable |

5 Encapsulation Message Formats

The following are the formats of the messages used to encapsulate frame data over TCP connections. The TCP/IP host is expected to implement one of these methods if message preservation is required.

Count (length) fields are in network byte order (big endian) with most significant byte first, least significant byte last.

5.1 MBIT (2-byte count field)

Simple encapsulation of data using a 2-byte length field. Used to encapsulate and demarcate frame data. Each MBIT message contains the data from an individual frame. The purpose is to preserve the boundaries of application messages.

| | |
|-----------|-------------------|
| Count = x | Payload (x bytes) |
|-----------|-------------------|

Error detection is not performed on the header, and any error will cause data loss and/or stalling.

5.2 RFC1006 (ISO TP)

Encapsulation method to provide ISO Transport Service for bridging between X.25 and TCP hosts. Preserves application message boundaries similar to MBIT above, and can be used as an alternative to MBIT. The header is 4 bytes.

| | | | |
|----|----|-------------|-------------------|
| 03 | 00 | Count = 4+x | Payload (x bytes) |
|----|----|-------------|-------------------|

Error detection is performed on the header, and any errors will cause the connection to be terminated.

6 Contact Microtronix

Microtronix Datacom Ltd.
4056 Meadowbrook Drive, Unit 126
London ON N6L 1E3
CANADA

Tel: +1 519 690-0091
Fax: +1 519 690-0092

General Inquiries: info@microtronix.com
Sales Enquiries: sales@microtronix.com
Customer Support: support@microtronix.com