

**Locate the two wires going from the rectifier to the brushes, LEAVE THEM CONNECTED!! Cut both excitation wires and connect as shown.**

