

# aerocoach

## **Align Curve carbon arm rests**

**Please read these instructions carefully - non-compliance will void the warranty which applies to the original owner**

The AeroCoach carbon fibre Align Curve universally compatible arm rests keep you locked in place when in the aerobars, making you safer, more stable and more aerodynamic.

### **Please note:**

- You must NOT drill the arm rests in any location
- In the event of crash impact, the arm rests should no longer be used. Please contact AeroCoach and we will be happy to advise you of our crash replacement policy

### **Installation:**

- Remove your current aerobar arm rests and replace with Align Curve carbon arm rests
- Ensure that you use the metal spherical washers provided with the arm rests directly underneath the head of the bolts used to secure the arm rests. Bolts with a flat underside to them (e.g. button head) should be used - **do not use tapered or v-head bolts.**
- Each arm rest must be secured with 2 bolts, which can be mounted through any 2 of the slotted holes.
- If installing Align Curve arm rests with AeroCoach angled spacers or AeroCoach 5deg or 10deg arm rest wedges for Ascalons, you do not need the angled washers that come with angled spacers / wedges, due to the use of metal spherical washers.
- Please refer to your aerobar manufacturer's recommended torque settings during installation.

**Please check your equipment before each ride - if you see any damage then you should not use the bicycle until it has been inspected**

AeroCoach LTD does not accept any liability for issues arising due to non-compliance of these instructions. If you are unsure about the setup of your Align Curve carbon arm rests, please contact [customerservice@aero-coach.co.uk](mailto:customerservice@aero-coach.co.uk)