



Align Wing carbon arm rests

Please read these instructions carefully - non-compliance will void the warranty which applies to the original owner

The AeroCoach carbon fibre Align Wing universally compatible arm rests keep you locked in place when in the aerobars, making you safer, more stable and more aerodynamic.

Please note:

- You must NOT drill the arm rests in any location
- In the event of crash impact, the arm rests should no longer be used. Please contact AeroCoach and we will be happy to advise you of our crash replacement policy

Installation:

- Remove your current aerobar arm rests and replace with Align Wing carbon arm rests
- Ensure that you use the metal washers provided with the arm rests directly underneath the head of the bolts used to secure the arm rests. Bolts with a flat underside to them (e.g. button head) should be used – **do not use tapered or v-head bolts.**
- Each arm rest must be secured with 2 bolts, which can be mounted through any 2 of the slotted holes.
- If installing Align Wing arm rests with AeroCoach angled spacers and washers, please use the angled washers directly on top of the Align Wing arm rests, and the provided metal washers directly under the bolt heads.
- Please refer to your aerobar manufacturer's recommended torque settings during installation.

Please check your equipment before each ride - if you see any damage then you should not use the bicycle until it has been inspected

AeroCoach LTD does not accept any liability for issues arising due to non-compliance of these instructions. If you are unsure about the setup of your Align Wing carbon arm rests, please contact customerservice@aero-coach.co.uk