



Canyon Gear Groove adapter with tilt blocks and extension clamps

Many thanks for your purchase: please read the following instructions carefully as issues caused by failure to adhere to the instructions will not be covered by warranty.

Please note:

- You must NOT modify the parts in any way.
- Metal parts of the assembly be cleaned of all corrosive elements, such as sweat or saltwater, and allowed to air dry freely following use.

Assembly:

- If you are not familiar with the installation of aerobar extensions, please consult your local bike shop for advice.
1. Disassemble all current parts from the mounting point on the handlebar including the Canyon Basespacer.
 2. Attach the AeroCoach Canyon Gear Groove adapter to the handlebar using the M6 16mm screws supplied by Canyon, according to the Canyon torque recommendations.
 3. Align the AeroCoach extension clamps on top of the tilt blocks, using the provided M6 12mm button head bolts (bolt heads inside the top of the tilt blocks) - recommended torque is 5-6Nm.
 4. Place the AeroCoach tilt blocks onto the mounting points of the adapter arms, and insert the threaded bars into the slots of the tilt blocks. Secure the tilt blocks to the adapter arms using the provided M6 12mm button head bolts (recommended torque 5-6Nm). If you are using AeroCoach tilt block stackers, these should be placed on the mounting points of the adapter arms before adding the tilt blocks, and secured using the correct length of longer bolts purchased as an 'extra bolt pack'.
 5. Once the tilt blocks are secured to the Canyon Gear Groove adapter or stackers, insert 22.2mm diameter extension poles into the extension clamps.
 6. Place AeroCoach Align Wing carbon arm rests onto the extension clamps, and secure the arm rests onto the extension clamp using the M5 14mm button head bolts, with washers provided, to secure both the arm rests in position and the extension clamp around the extension poles (recommended torque 4-6Nm).
 7. If angled spacers or other spacers are used between the bottom of the arm rests and top of the extension clamps, please note that longer bolts (not provided) will be required - please ensure that the M5 bolts used are long enough to engage with all the threads in the extension clamp.

Please check your equipment before each ride - if you see any damage then you should not use the bicycle until it has been inspected

AeroCoach LTD does not accept any liability for issues arising due to non-compliance of these instructions. If you are unsure about the setup of your AeroCoach components, please contact customerservice@aero-coach.co.uk