



STEP 1



1. PREPARE STILE AS SHOWN.
2. INSERT BINDER POST THRU .265 DIA. HOLE IN STILE.
3. SECURE BINDER POST WITH 1/4-28 NUT.
(CAUTION: DO NOT OVERTIGHTEN NUT)


STEP 2



1. INSTALL 4500, 4700 AND 4900 SERIES DEADLATCH PER MOUNTING INSTRUCTIONS.
2. INSTALL 4580 CAM DISC ASSY. SECURE WITH SETSCREW.


INSTALLATION

STEP 3




1. INSTALL ESCUTCHEON ASSY.
2. USING 8-32 SCREWS W/LOCKWASHER, SECURE ESCUTCHEON ASSY. TO BINDER POST.
IMPORTANT,
TIGHTEN THESE SCREWS SECURELY.

STEP 4




1. INSTALL PADDLE ASSY. ALIGN DRIVE EARS ON PADDLE WITH SLOT IN DRIVE PLATE.
2. INSTALL PIVOT PIN.
3. INSTALL PIVOT PIN SET SCREW. TIGHTEN SET SCREW FLUSH WITH BOTTOM OF ESCUTCHEON.

INSTRUCTIONS FOR CHANGING HAND SEE REVERSE FOR CAM DISC ASSY.




1. FIND DESIRED CONFIGURATION.
2. REMOVE KEEPERS TO SEE LOCATION OF SPRINGS & DRIVER PLATE.
3. REVERSE SPRINGS & DRIVER PLATE IF NECESSARY.
4. REMOVE DRIVER SCREW IF NECESSARY, AND PLACE IN DESIRED LOCATION.



5. REPLACE KEEPERS.
6. CONFIGURE CAM DISC. (SEE REVERSE)

4580 CAM DISC HANDING


LOOKING AT THE EDGE OF THE DOOR, DETERMINE ON WHICH SIDE THE HANDLE OR OTHER OPERATOR IS TO BE INSTALLED.




THE CAM DISC MUST BE HANDED AS SHOWN.



ON THIS SIDE




ON THIS SIDE




THE CAM DISC MUST BE HANDED AS SHOWN.

INSTRUCTIONS FOR CHANGING HAND OF 4580 CAM DISC


STEP 1




STEP 2



STEP 3



STEP 4



www.adamsrite.com
Phone: 800-626-7590
800-872-3267

Fax: 866-582-4641
800-232-7329

ASSA ABLOY

4591 PADDLE OPERATOR

80-0180-200

Rev. E

ECN: 11955A

Date: 06-19-12

INSTALLATION INSTRUCTIONS

Page 2 of 2 Appvd: MP Date: 06-19-12