



ASSEMBLY & INSTALLATION GUIDE - *CORRUGATED AWNING*

TOOLS & MATERIALS REQUIRED

- Paint (exterior)
- Sandpaper
- Filler
- Tape measure
- Tin snips
- Gloves (optional)
- Power drill
- Tek drill bit
- Texta
- String line (optional)
- Square
- Phillips bit
- Circular saw

NOTES

- Professional installation recommended if uncertain.
- DIY assembly is at your own risk.
- 1.2mtr kits do not require connector sleeves.
- Before starting, Measure your window (outside architrave to outside + 10mm clearance minimum). This determines back bar size.
- Fixing to house - we recommend Dyna bolts for brickwork and Bugle screws for weatherboard

INSTALLATION INSTRUCTIONS

1. Unpack all items and familiarise yourself with all components - (VIEW PACKING DOCKET FOR LIST OF ITEMS)



2. Paint primed timber sides. Apply two top coats of exterior paint and allow to dry.

3. Fix two metal triangle brackets to each timber side as pre-marked.



4. Join front bars using silver connector sleeves (to extend)

Insert halfway into one side by squeezing, then connect the other.

Secure with stitch screws to prevent sagging. (for 1.8, 2.4 & 3mtr wide awnings only) Repeat the process to create the back bar.



5. If required, cut support bars to desired size:

Back bar = measured size.

Front bar = back bar + 20mm (to allow for notch in timber brackets)

Remove protective plastic from bars.

6. Attach front and back bars to timber sides using triangle brackets and secure with tek screws.



7. Place white boards on frame. Mark, trim, and fix into place ensuring level and square. Allow ~100mm front overhang.

8. Lay down your roofing sheets by evenly overlapping them. Keep them flush to the back and overhang on the front.



9. Screw them down into the two support bars beneath.

10. Fit side caps. Mark angles, cut with tin snips, and secure with tek screws.



11. Fit back cap. Adjust length, cut, and secure. Remove all protective film and clean surfaces.

12.. Install awning using supplied hooks window to your desired position. Level and fix securely to the house.



13.. Final check and Enjoy your new window awnings!

