

FITTING INSTRUCTION - VARIATIONS

The longer return fold sits on top of the tub and is fixed into the side of the tub with rivnuts.

NOTE: Silicon seal all along underside of infill to tub.

Drill 1 @ Ø9 hole (in each side of the tub) and fit M6 rivnuts using the correct insertion tool.

Fasten the infill panel to the tub using:

- 2 @ M6 x 20 S/S button head socket screws, S/S spring & S/S penny washers.

Once the infill is fastened in place, drill and rivet in 4 places.



M6 S/S rivnuts



Rivnut insertion tool

2015-current TOYOTA HILUX J DECK Infill Panel

