

QD-200 Installation Instructions

Step Number	Description	Image
1	Insert custom jack and secure with jack mounting bracket and (2) $\frac{3}{8}$" x 1$\frac{1}{2}$" carriage bolts and (2) $\frac{3}{8}$" flange nuts . Jack wheel is stowed on the side of the "A" Frame.	
2	Attach jack handle plate to side of dovetail and secure with (2) $\frac{3}{8}$" x $\frac{3}{4}$" carriage bolts and (2) $\frac{3}{8}$" flange nuts	
3	Insert jack handle extension through jack handle plate and onto jack . Secure with (1) $\frac{1}{4}$" x 1" and (1) $\frac{1}{4}$" lock nut through the pre-drilled hole. A hammer can be helpful to get the jack handle extension onto the jack .	
4	Connect a stabilizer arm to each side of the dovetail using (2) $\frac{7}{16}$" lynch pins on each.	

QD-200 Parts List

Custom Jack		1
Jack Wheel		1
Jack Extension Handle		1
Jack Mounting Plate		1
Jack Mounting Bracket		1
Stabilizer Arm		2
$\frac{7}{16}$ " Lynch Pin		4
$\frac{3}{8}$ " x $1\frac{1}{2}$ " Carriage Bolt		2
$\frac{3}{8}$ " x $\frac{3}{4}$ " Carriage Bolt		2
$\frac{3}{8}$ " Flange Nut		4
$\frac{1}{4}$ " x $1\frac{1}{4}$ " Bolt		1
$\frac{1}{4}$ " Lock Nut		1