

Hybrid Navigator Caravan Setup Checklist

1. Position and Level the Caravan

- Park on a flat, stable surface.- Use leveling ramps or chocks if needed.- Lower the 4 stabiliser legs located under the van using the winding tool (found in the front compartment). > Wind them down until firm on the ground — do not use to lift the van.

2. Unhitch from Tow Vehicle

- Engage the handbrake.- Locate the jockey wheel winding tool inside the front compartment.- Insert the tool into the hole at the top of the jockey wheel and wind the wheel up or down.- On the jockey wheel shaft, remove the locking pin, extend the lower section to the ground, and reinsert the pin to lock it.- Once the jockey wheel is fully supporting the van, continue winding to raise the drawbar off the tow ball.- Disconnect the safety chains and electrical plug from the vehicle.

3. Raise the Roof

- Press the electric roof lift button (inside the entry door area).- Wait for the roof to lift completely. Visually check all four corners are raised evenly.

4. Connect Utilities

- Connect the fresh water hose from the tap to the caravan inlet.- Connect the grey water hose and direct the outlet to an appropriate drain or bucket.- Turn on the gas bottle if needed.- Plug in the 240V power lead only if using mains power. > If you're not using 240V, the van will run on 12V power from the solar panels and battery. > Make sure the 12V button (located on the internal control panel) is switched on to activate 12V power.

5. Deploy Awning (if applicable)

- Unclip and roll out the awning carefully.- Extend the awning support poles and adjust them into position.

6. Final Checks

- Open windows and roof vents for airflow.- Check that the selected power source (12V or 240V) is functioning.- Ensure all exterior doors, compartments, and hitch area are secure.- Confirm all loose items inside the van are stowed safely.

Hybrid Navigator Caravan – Kitchen Setup Checklist

1. Unlock and Slide Out the Kitchen

- Unlock and open the external kitchen compartment door.- Unlatch the kitchen unit and carefully slide it out from the van.- Undo the latch that allows the kitchen to swing out into position.- Swing the sink section around to form the L-shaped kitchen layout.- Latch the kitchen latch into the side of the van (it flips into a small latch point).

2. Set Up the Fridge Side

- Pull out the fridge slide compartment by: • Unlatching the latches on either side. • Pressing down the blue tabs on each side. • Fully sliding the fridge section out.- Once fully extended, lower the stabiliser legs and lock them into place.- Unlatch and lower the fridge-side bench (two latches, one on each side).

3. Set Up the Sink Side

- Fold out the left-hand bench/table section.- Lift the main top lid to expose the sink and stove.- Raise the support arms on either side of the stove top to hold the lid up.- Remove the foam pads from the gas burner plates and store them safely.- Connect the gas hose under the sink to the gas outlet.- Connect the water hose under the sink to the water outlet. • Make sure both connections are fully inserted and secure.

4. Final Checks

- Turn on gas and water at their sources (if not already on).- Test the tap and stove briefly to ensure both are working.- Make sure all surfaces are stable and latches are secured.

Hybrid Navigator Caravan Pack-Down Checklist

****Important:**** Before starting, pack up the kitchen first and ensure all external door compartments are fully closed. If left open, they may hit the ground when lowering the van and can get damaged.

1. Prepare Interior and Secure Items

- Ensure all windows and roof vents are closed.- Turn off any internal appliances.- Lock the mirror into travel position.- Ensure the TV is flat/level and secure for travel.- Stow all loose items securely inside the van.

2. Retract Awning (if deployed)

- Retract and roll up the awning.- Fold and secure the awning support poles into their storage position.- Clip the awning in place for travel.

3. Lower the Roof

- Press the electric roof button to lower the pop-top roof.- Ensure all canvas is tucked in neatly as it lowers.- Visually check that all four corners lower evenly.- Confirm the roof is fully down and latched into place.

4. Disconnect Utilities

- Turn off the gas bottle.- Disconnect and store the grey water hose.- Disconnect and store the fresh water hose.- Unplug the 240V power lead (if connected).- Turn off the 12V button on the control panel if not needed during transit.

5. Raise Stabiliser Legs

- Use the winding tool from the front compartment.- Wind up all 4 stabiliser legs fully.- Return the tool to its storage spot.

6. Reconnect to Tow Vehicle

- Line up the tow vehicle and lower the drawbar onto the tow ball using the jockey wheel.- Reinsert the pin to lock the jockey wheel shaft.- Wind the jockey wheel up to raise the van.- Secure the jockey wheel by removing the pin, lifting the pole all the way up to the top, then locking the pin back in place.- Reconnect the safety chains and electrical plug.- Ensure the car's lights are turned on — this activates the electric brakes.- Disengage the handbrake once fully connected.

7. Final Walkaround

- Double-check all external compartments, doors, and windows are locked.- Ensure the awning is clipped in place.- Confirm the roof is latched down securely.- Verify all hoses, leads, and gear are packed away.- Do one final walkaround the van to check:

- All latches are locked
- Stabiliser legs are up
- Roof vents and windows are closed
- The step is folded in

Hybrid Navigator Caravan – Kitchen Pack-Down Checklist

****Important:**** The entire kitchen must be packed away before hooking the van up to your car, or the open doors will hit the ground and may break off.

1. Clean & Fold Down Kitchen

- Clean the bench, sink, and stove top.- Remove any personal items or utensils.- Under the sink: • Disconnect the water hose from the van fitting. • Let any remaining water drain out. • Carefully place the water hose up into the sink compartment, ensuring it's not hanging out.- Disconnect the gas fitting from under the sink and stow the hose back into its place.- Place the foam pads back over the gas burner plates.- Fold down the arms that support the lid (located on either side of the stove top).- Close the main top lid over the kitchen.- Fold the left-hand bench/table section over the top to complete the pack-down.

2. Fold and Secure the Fridge Side

- On the fridge side of the outdoor kitchen: • Raise the stabiliser legs located under the fridge slide. • Pull up the bench section attached to the fridge and clip it back into place. • Push all drawers fully in. • Shut and lock the compartment door.

3. Fold and Secure the Sink Side

- Unlatch the kitchen from the van.- Fold the sink section back around (it swings on a hinge like an L-shape).- Latch the locking clip to secure it in position.- Slide the kitchen fully back into the van.- Latch it in place once it's fully in.- Shut and lock the external compartment door.