


## DRIVERS SIDE DOOR WINDOW

Insure window crank has adequate room for operation.



Avoid bending the first 14" of the cable as much as possible. Avoid all hot, rotating and sharp chassis components when routing cables.

DASH

VF-01

Drill 2 pilot holes  $7/64$ " through plastic into steel rib behind it. Fasten bracket with (2) No. 12x1- $1/2$ " sheet metal screws. Do not overtighten.

Remove plastic plug. Attach tail of VF-01 bracket to kick panel with 5/16 self tapping screw.

Drill  $11/16$ " holes in floor for cables.

KICK PANEL

FLOOR

## Installation Instructions VF-01 Dash Bracket 1987-91 Ford