Converting Hydra FLKR for appropriate bale size

- 1. If Hydra FLKR is mounted on Hydra Bed, remove clamp hooks from each side and slide Hydra FLKR rearwards approximately 18" to 24".
- 2. Using a 3/16" Allen wrench, remove (4) 5/16 x ½" Button Head Cap Screws from top of platform.
- 3. Using (2) ½" wrenches and/or ratchets, loosen 3 bolts/nuts (A) and remove 1 bolt/nut (B) from platform support brackets on each end of underneath of platform Hydra FLKR.
- 4. Slide platform forward (for 3-ft. wide bales) or rearward (for 4-ft. wide bales) 6 inches to second series of (4) holes on top of platform.
- 5. Replace (4) Button Head Cap Screws on top of platform.
- 6. Tighten bolts/nuts (A) and replace bolt/nut (B) to platform support bracket underneath Hydra FLKR platform.

