## **Kartech Remote Pairing Instructions**

Each radio transmitter is preprogrammed with a unique radio ID code. Each receiver is programmed to respond only to the radio transmitter with the ID code for which it is set. This feature allows multiple systems to work in close proximity to one another without interference. In the event that a transmitter becomes damaged and a new one is needed, the receiver can be reprogrammed to respond to the new radio transmitter. To teach the ID code to the receiver, use the following procedure:

- 1. Remove receiver cover
- 2. Apply power to the receiver
- 3. Place a jumper across the address code jumper inside the receiver. Both green and red LEDs will toggle inside the receiver. Remove the jumper and store it on one pin
- 4. To get the transmitter into TEACH ID mode, press and hold the POWER button, button 1 and button 8. At this point, both LEDs will blink on the transmitter
- 5. Release the POWER button and wait for 1 second or until the green and red LEDs stop toggling in the receiver. Release the other buttons
- 6. Teach complete
- 7. Replace the cover on the receiver

