



REGENERATION INSTRUCTIONS

1. Using a clean bucket, fill with approx. 5L of aquarium water.
2. Add 300g of softening salt tablets.
3. Agitate using an air-stone, until salt turns into brine.
4. Add up to 3 used Nitrate Remover Pods.
5. Leave tumbling overnight.
6. Remove Pods from the water.
7. Discard the dirty water.
8. Rinse bucket & refill with approx. 5L of aquarium water.
9. Agitate using air-stone for 15min to wash the Pods.
10. Regeneration complete.