



Brisbane Fridge and Freezer Seals
07 3849 4126
admin@brisbaneseals.com.au
341a Kelvin Grove Rd, Kelvin Grove

HOW TO FIT YOUR STRIP CURTAIN

Face Mount

Tools Required: Spirit Level, Drill, Scissors, Adjustable Wrench

Preparation: Check construction, soundness and level of door frame and jamb. Ensure to mount only to a surface that can support the weight of the curtain.

Notes: Face Mount Curtains are designed to sit above door opening.

Step 1: Install The Header Rail. Install the header rail horizontally and evenly above door opening by drilling through header rail into fixing surface. Fit bolts provided inside header channel, sliding all bolts in from one end prior to mounting.

Step 2: Install the PVC Strips. Each strip is pre-punched to suit bolts and to give required overlap for maximum hygiene and insect repellent efficiency. Mount every other strip noting that last bolt hole in one strip overlaps first hole of adjacent strip and then once you reach the end go back and add in the missing strips, this creates an under/over pattern which stops the strips moving as a sheet.

Step 3: Tighten Fixings. Place washers and nuts and lightly tighten. When all strips are in place, tighten nuts firmly. Check to ensure that bottom of the strips clear the floor by 5-10mm distance. Trim bottom of strips if necessary.

Step 4: Allow to Settle. PVC strips may take short period of use to hang true and may stretch over time. If this occurs, trim as necessary to ensure 5-10mm clearance to floor.