



Before Starting:

Predetermine layout and determine elevation and slope changes. Panels are not designed to rack. When setting post depth remember that the fence is designed for a 2" space between the bottom rail and the ground.

Installation Procedure :

- 1.) Place postholes on 72" centers for 6' sections and 96" for 8' sections.
- 2.) Center 7/8" U-channel for T&G pickets on posts and attach with SS screws. (1 screw at top and bottom, then 1 screw approximately every 16")
- 3.) Slide aluminum reinforcement channel into the bottom rail. Place rail locks into the bottom rail and lock into posts.
- 4.) Slide T&G pickets into place. When the T&G pickets are completely loaded, install the mid-rail into posts (no rail locks).
- 5.) Center U-channel for lattice on posts, top rail and mid-rail, attach with SS screws. (2 screws to hold the U-channel on the posts. Space screws approximately 16" apart when attaching U-channel to the top rail and mid-rail)
- 6.) Install lattice by sliding it down into the U-channel on the posts to rest in the U-channel on the mid-rail.
- 7.) Place rail locks into the top rail and set on lattice. Lock into place.

Rail Lock Installation :

