

Shipping Instructions

- 1. Freeze Cold Packs the night before shipping.**
- 2. Rinse carboy with sample water before filling to top.**
- 3. Fill carboy with sample (no headspace) and secure lid with tape.**
- 4. Place carboy in cooler and place cold packs on TOP of carboy.**
- 5. Include instruction sheet with Name, Date and Test to perform.**
- 6. Secure lid of cooler with tape and ship overnight to:**

**Engineering Performance Solutions
3161 St. Johns Bluff Road S. Suite 3
Jacksonville, FL 32246**

**If you have any questions call:
Rick Loftis
904-645-7775**