# **Building Codes that Regulate Decorative Chimney Shrouds**









## International Mechanical Code 2000

#### M74-98 806.6 Ratified 9/98

Now the Model Building Code for the U.S.

806.6 Decorative Shrouds. Decorative shrouds shall not be installed at the termination of factory-built chimneys, except where such shrouds are listed and labeled for use with specific factory-built chimney systems and are installed in accordance with section 304.1

Reason: Decorative shrouds have been the cause of roof and chase fires...

### International Residential Code 2000

#### R1004.3 Ratified 9/99

Now the Model Building Code for the U.S.

1004.3 Decorative Shrouds. Decorative shrouds shall not be installed at the termination of factory-built chimneys, except where such shrouds are listed and labeled for safe use with the specific factory-built chimney system and are installed in accordance with manufacturers installation instructions.

Reason: Decorative shrouds often allow for the creation of temperatures in excess of those permitted in UL103 and UL127. Decorative shrouds have been the cause of chase top fires...

## International Fire Code **2000**

#### IFC 603.6.3 Ratified 9/99

Now the Model Building Code for the U.S.

603.6.3 Decorative Shrouds. Decorative shrouds installed at the termination of factory-built chimneys shall be removed, except where such shrouds are listed and labeled for use with the specific factory-built chimney system and are installed in accordance with manufacturers installation instructions.

Reason: Decorative shrouds have been the cause of dozens of chase fires. As a non-listed part to a listed assembly, their use should not have been allowed in the first place.