

COMMANDER MAT LD (LT TACK MAT)

PRODUCT SHEET



PRODUCT DESCRIPTION

Commander Mats LD (LT Tack Mats) are perfect for commercial and residential jobs, protecting surfaces from foot traffic, stains and ladders. Commander Mats/LT Tack Mat feature a specialised adhesive backing, allowing them to adhere seamlessly to the substrate. Suitable for use for up to 12 months on internal projects only.

FEATURES & BENEFITS

- Adhesive backing preventing dust & dirt from scratching the surface
- Ideal for use under foot traffic, ladders and small trolleys.
- Easy to install & remove (no residue left behind)
- Slip-rated surface
- Perfect for vertical surfaces, such as doors and surfaces of lift/elevators
- Ideal for stairs, windows, counter tops, joinery & more
- Stays in place, preventing trip hazards on site
- Prevents stains, such as paints, oils, some chemicals

USES & LIMITATIONS

- Porcelain & ceramic tile
- Engineered hardwood floors (not suitable for use on non-factory finished hardwood)
- Most stone tiles* (not suitable for use on bluestone/limestone/concrete)
- Sheet vinyl & laminate
- Glass, epoxy, metal, bathtubs, sinks & counter tops
- **Not to be used on acrylic surfaces**
- All adhesives have the potential to lift finished coatings or paint depending on the condition and age of the surface. Testing a small piece in a non-critical area will help you judge suitability for use
- Not for use on external or projects exposed to the elements. Suitable for use between -10 to 50 degrees celsius
- Ideal for use on the following projects: health & education, data centres, high-end residential, hospitality, sports & recreation sectors
- Humidity may affect application on vertical surfaces

SPECIFICATIONS

- Roll Size: 1m x 50m
- Square Meterage: 50m
- Colour: Light Grey
- Roll Weight: 20kg
- **Product Code: CMLD20**
- **Speak with your Honcho rep to ensure suitability**



Prevents Stains



Slip Rated



Water Resistant



Prevents Scratches



UV Resistant



Easy Application
& Removal

Disclaimer: Customers are advised to consider the information in this data sheet in the context of how the product will be used, including surfaces and any other products used. The information provided in this guide represents our best scientific and practical knowledge. Any advice, information or assistance provided by Honcho Supplies in relation to its products is given in good faith, however is provided without liability or responsibility. Due to the wide variety of site conditions we are unable to assume liability for any loss that may arise from the use of our products. The user is responsible for checking the suitability of products for their intended use.

COMMANDER MAT LD (LT TACK MAT) INSTALLATION GUIDE



INSTALLING THE MATS

1. Ensure surface is completely clean and dry
2. Locate the spot where the release paper joins the clear plastic film on the back of the mat
3. Peel back 1-2 metres of the release paper. Fold this section back underneath the mat roll
4. Ensure to properly align the roll so that you end up with a straight install
5. Attach the adhesive side to the surface and press in firmly to create a good bond and then continue to roll out mat, while releasing backing paper. For best results, we recommend working in pairs and use a paint roller to press mat in while it's being rolled out
6. Once the first row has been completed, begin the process with the second row, overlapping the first row (using the dotted line) approx 3cm in. This will prevent dirt/debris from getting in underneath the mat.
7. Continue the process until the entire area is covered. We recommend covering the whole surface to reduce the risk of uneven UV exposure.
8. The mat can be lifted to inspect the substrate at any time or re-adjusted as needed.

For protection of stairs: Start from the bottom and pull the release paper up while moving the roll up the stairs - ensure to push/press the TackMat down onto all the treads and risers.

9. All adhesives have the potential to lift finish coatings or paint, depending on the condition/age of the surface. We recommend testing a small area prior to installation. We recommend testing a small section prior to install



REMOVING THE MATS

At the end of your project, simply lift mats from the surface and discard.

Temperature for removal should be between 10 to 38 degrees celsius

CONSIDERATIONS - READ BEFORE APPLYING

Our Adhesive Mats should not be applied to the following substrates:

- Polished concrete
- Concrete that has not fully cured
- Limestone/basalt
- Non-factory finished hardwood flooring
- Any exterior surfaces
- **Always consult with your Honcho rep to ensure substrate suitability.**



Disclaimer: Customers are advised to consider the information in this data sheet in the context of how the product will be used, including surfaces and any other products used. The information provided in this guide represents our best scientific and practical knowledge. Any advice, information or assistance provided by Honcho Supplies in relation to its products is given in good faith, however is provided without liability or responsibility. Due to the wide variety of site conditions we are unable to assume liability for any loss that may arise from the use of our products. The user is responsible for checking the suitability of products for their intended use.