

WickRight Clay Coping Vent

Function: For venting masonry parapets, finished with Clay Copings.

- **Material:** Polypropylene
- **Sizes:** 3"
- **Length:** Sold in 4 foot lengths
- **Pricing:** Call for quote

How to Order: Measure wall perimeter, add 10%. **Example:** 180' perimeter → order 200' Order with equal amount of **WickRight Vapor Permeable Membrane** appropriate for the width of parapet wall.

Installation:

- Install centered on top of parapet wall open side down with 2 beads of polyurethane sealant applied to solid edges of **WickRight Clay Coping Vent**
- Position length-wise in the middle of the wall

Requirements: Install **WickRight Vapor Permeable Membrane** over Clay Coping Vent

Resources: Installation guide available at WickRight.com.



