

Aussie UnderCover® - Strut setup

SUPER, SUPERPLUS and CUSTOM (6 STRUT) SYSTEM

Struts must be installed with the Barrel at the top and the shaft/stroke at the bottom, as shown in diagrams

Refer to plans for installation dimensions

Diagrams are representations only; your actual frame may look slightly different.



Power21 Outside
Struts with handwheel

Outside Struts – 525 mm - **140mm** up from base of frame to center of ball



Inside Struts – 455mm - **100mm** up from base of frame to center of ball

Full installation details, measurements and plans in the installation instructions

