

Information about how to change a dust bag!

1 step

Take a dust bag and wrap it around the rubber band which is on the fan.



2 step

Now you need to open the edge of the rubber band and put the dust bag between two edges. Do it from the both sides- from the right and from the left.



3 step

Dust bag must be correctly deployed.

Switch on a dust collector and then dust bag will be pushed up with space (see in the picture).



Warning!

1. Please, change the dust bags every day.
2. Dirty dust bags must be washed with warm water only by hands. Do not put dust bags in the washing machine.
3. Be sure that the dust bag has been put on a fan according to this instruction. If you have dust everywhere, it means that the dust bag has been put on the fan in a wrong way.