

LAUNDRY BAG



FABRIC: Bright cottons, baby prints (no Santa or witches)

DRAWSTRINGS: Braided (chained) Yarn, Ribbon, Thin Cord or Thick String

PATTERN: Cut fabric 16" x 14" (finished bag will be 13"W and 15" L).

LABEL: Sew label on front side of fabric, placing the label 2" from the bottom on the right side of the fabric.


SEWING:



Serge, zig zag stitch, or "pink" the edges of the right side of two pieces of fabric.

Place the right sides together, sew-allow 3/8" seam allowance.

On this right side when you are sewing down this right side, back tack, sew down for 1" and back tack. Next leave a 1" space, back tack again and continue sewing the rest of the right side seam. This will prepare an opening for the drawstring.



Open the right side at the top and top stitch. See diag.



Sew across the bottom two pieces, then the left side together, then serge, zig zag, or "pink" these two stitched seams.

Serge, zigzag, or "pink" the entire top edge of the bag.

Fold the top 1" down towards the inside of the bag starting with the 1" opening. This will be the beginning and end of the top stitching for the yarn or string drawstring.

FINAL STEPS: IRON both sides, then using a safety pin pull the yarn, string or ribbon through the casing. Leave 5 extra inches, knot the ends leaving 1".