




MF1 Manual Controller

Wiring Diagram



!! ENSURE A 30A FUSE IS PLACED IN THE CIRCUIT BETWEEN THE POSITIVE POWER SUPPLY AND THE POSITIVE TERMINAL OF THE MOTOR (BEFORE THE SWITCH) !!