




Repair Parts Sheet

FBEW-3000S

FBEW Series – Battery Torque Wrench

Doc. : B00

Date:2023-08



Item NO.	Description	Qty	Part NO.
			FBEW-3000S
1	Circlip	1	FBEW-3000S-01
2	Reaction Arm	1	FBEW-3000S-02
3	Screw	1	FBEW-3000S-03
4	Gear Case	1	FBEW-3000S-04
5	Copper Bush	1	FBEW-3000S-05
6	Washer Optional	1	FBEW-3000S-06
7	Circlip	1	FBEW-3000S-07
8	Gasket	1	FBEW-3000S-08
9	Square Drive	1	FBEW-3000S-09
10	Fourth-Stage Planet	1	FBEW-3000S-10
11	Planet Gear	4	FBEW-3000S-11
12	Planet Pin	4	FBEW-3000S-12
13	SM Bush	1	FBEW-3000S-13
14	Washer	1	FBEW-3000S-14
15	Third-Stage Planet	1	FBEW-3000S-15
16	SM Bush	4	FBEW-3000S-16
17	Planet Gear	4	FBEW-3000S-17
18	Planet Pin	4	FBEW-3000S-18
19	Washer	1	FBEW-3000S-19
20	SM Busher	1	FBEW-3000S-20
21	Washer	1	FBEW-3000S-21
22	Second-Stage Planet	3	FBEW-3000S-22
23	Planet Pin	3	FBEW-3000S-23
24	Planet Gear	3	FBEW-3000S-24
25	SM Bush	1	FBEW-3000S-25
26	Gasket	1	FBEW-3000S-26
27	SM Bush	1	FBEW-3000S-27
28	Washer	3	FBEW-3000S-28
29	Planet Pin	3	FBEW-3000S-29
30	Planet Gear	3	FBEW-3000S-30
31	SM Bush	1	FBEW-3000S-31
32	First-Stage Planet	1	FBEW-3000S-32
33	SM Bush	1	FBEW-3000S-33
34	Washer	1	FBEW-3000S-34
35	Gasket	1	FBEW-3000S-35
36	Input Shaft	1	FBEW-3000S-36
37	Bearing	1	FBEW-3000S-37
38	Smaller Gear Case	1	FBEW-3000S-38
39	Locking Ring	1	FBEW-3000S-39
40	Bearing	1	FBEW-3000S-40
41	Handle Support	1	FBEW-3000S-41
42	Screw	1	FBEW-3000S-42
43	Screw	1	FBEW-3000S-43
44	Handle Cover	1	FBEW-3000S-44
45	Forward / Reverse Shuttle	1	FBEW-3000S-45

46	Shuttle Spring	1	FBEW-3000S-46
47	Screw	1	FBEW-3000S-47
48	Foam Pad	1	FBEW-3000S-48
49	High Voltage Screw	1	FBEW-3000S-49
50	Service NamePlate	1	FBEW-3000S-50
51	Electronics Assembly	1	FBEW-3000S-51
52	Rotor Assembly	1	FBEW-3000S-52
53	Speed Switch Assembly	1	FBEW-3000S-53
54	Housing Assembly	1	FBEW-3000S-54
55	Digital Controler	1	FBEW-3000S-55

