

BT **B** **I** **A**
T **0** **0** **L** **S**

LOW PROFILE
SINGLE ACTING


MODEL: SL-502

Form. # 10013

sales@bia-tools.com www.bia-tools.com

Not all components of cylinder are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence.

PARTS ILLUSTRATION





B I A
T O O L S

LOW PROFILE
SINGLE ACTING

MODEL: SL-502

Form. # 10013

sales@bia-tools.com www.bia-tools.com

PARTS LIST

ITEM	DESCRIPTION	QTY	SL-502
1	Coupler Cover	1	BT-QCC06
2	Quick Coupler	1	BT-QCF06
3	Cylinder Body	1	BT-SL502-3
4	Guide Sleeve	1	BT-SL50-4
5	Piston Rod	1	BT-SL502-5
6	Spring Fixing Sleeve	1	-
7-1	Spring Core	1	-
7-2	Spring (Included #6 And #7-1)	1	BT-SL502-7-2
8-1	Bolt	1	*
8-2	Bolt	1	*
9	Copper Washer	1	*
10	Seal Ring	1	*
11	Guide Ring on Piston	1	*
12	Wiper	1	*
13	Guide Ring on Guide Sleeve	1	-
14	Handle / Lifting Eyebolt	1	-
*	Included in Repair Kit	1	BT-SL50-RK