



B I A **T O O L S**

REGULAR SINGLE ACTING


MODEL : SR-102, SR-104, SR-106, SR-108

Form. # 10003

sales@bia-tools.com www.bia-tools.com

Not all components of cylinder are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence.

PARTS ILLUSTRATION





B I A T O O L S

REGULAR SINGLE ACTING

MODEL : SR-102, SR-104, SR-106, SR-108

Form. # 10003

sales@bia-tools.com www.bia-tools.com

PARTS LIST

ITEM	DESCRIPTION	QTY	SR-102	SR-104	SR-106	SR-108
1	Coupler Cover	1	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06
2	Quick Coupler	1	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06
3	Cylinder Body	1	BT-SR102-3	BT-SR104-3	BT-SR106-3	BT-SR108-3
4	Guide Sleeve	1	BT-SR10-4	BT-SR10-4	BT-SR10-4	BT-SR10-4
5	Piston Rod	1	BT-SR102-5	BT-SR104-5	BT-SR106-5	BT-SR108-5
6	Spring Fixing Sleeve	1	-	-	-	-
7-1	Spring Core	1	-	-	-	-
7-2	Spring (Included #6 And #7-1)	1	BT-SR102-7-2	BT-SR104-7-2	BT-SR106-7-2	BT-SR108-7-2
8-1	Bolt	1	*	*	*	*
8-2	Bolt	1	*	*	*	*
9-1	Copper Washer	1	*	*	*	*
9-2	Copper Washer	1	*	*	*	*
10	Seal Ring	1	*	*	*	*
11	Retaining Ring	1	-	BT-SR10-11	BT-SR10-11	BT-SR10-11
12	Spring Latch	1	-	BT-SR10-12	BT-SR10-12	BT-SR10-12
13	Piston Bearing	1	-	BT-SR10-13	BT-SR10-13	BT-SR10-13
14	Stop Ring	1	-	BT-SR10-14	BT-SR10-14	BT-SR10-14
15	Thread Protector	1	BT-SR10-15	BT-SR10-15	BT-SR10-15	BT-SR10-15
16	Adapter	1	BT-SR10-16	BT-SR10-16	BT-SR10-16	BT-SR10-16
17	Wiper	1	*	*	*	*
*	Included In Repair Kit	1	BT-SR10-RK	BT-SR10-RK	BT-SR10-RK	BT-SR10-RK