



B I A
T O O L S

REGULAR SINGLE ACTING


MODEL: SR-502, SR-504, SR-506, SR-5010, SR-5013

Form. # 10009

sales@bia-tools.com www.bia-tools.com

Not all components of cylinder are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence.

PARTS ILLUSTRATION





B I A **T O O L S**

REGULAR SINGLE ACTING

MODEL: SR-502, SR-504, SR-506, SR-5010, SR-5013

Form. # 10009

sales@bia-tools.com www.bia-tools.com

PARTS LIST

ITEM	DESCRIPTION	QTY	SR-502	SR-504	SR-506	SR-5010	SR-5013
1	Coupler Cover	1	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06
2	Quick Coupler	1	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06
3	Cylinder Body	1	BT-SR502-3	BT-SR504-3	BT-SR506-3	BT-SR5010-3	BT-SR5013-3
4	Guide Sleeve	1	BT-SR50-4	BT-SR50-4	BT-SR50-4	BT-SR50-4	BT-SR50-4
5	Piston Rod	1	BT-SR502-5	BT-SR504-5	BT-SR506-5	BT-SR5010-5	BT-SR5013-5
6	Spring Fixing Sleeve	1	-	-	-	-	-
7-1	Spring Core	1	-	-	-	-	-
7-2	Spring (Included #6 And #7-1)	1	BT-SR502-7-2	BT-SR504-7-2	BT-SR506-7-2	BT-SR5010-7-2	BT-SR5013-7-2
8-1	Bolt	1	*	*	*	*	*
8-2	Bolt	1	*	*	*	*	*
9-1	Copper Washer	1	*	*	*	*	*
9-2	Copper Washer	1	*	*	*	*	*
10	Seal Ring	1	*	*	*	*	*
11	Piston Bearing	1	BT-SR50-11	BT-SR50-11	BT-SR50-11	BT-SR50-11	BT-SR50-11
12	Thread Protector	1	BT-SR50-12	BT-SR50-12	BT-SR50-12	BT-SR50-12	BT-SR50-12
13	Wiper	1	*	*	*	*	*
14	Guide Ring on Guide Sleeve	1	*	*	*	*	*
15	Handle	1	BT-SR50-15	BT-SR50-15	BT-SR50-15	BT-SR50-15	BT-SR50-15
16	Adapter	1	BT-SR50-16	BT-SR50-16	BT-SR50-16	BT-SR50-16	BT-SR50-16
*	Included in Repair Kit	1	BT-SR50-RK	BT-SR50-RK	BT-SR50-RK	BT-SR50-RK	BT-SR50-RK