

Backwashing & Rinsing Filter

Service - Maintenance - Repair
994-2905



- 1** Turn off pump.
- 2** Unroll backwash hose if your filter is equipped with one.
- 3** Press down handle on top of filter & turn clockwise to Backwash position.
- 4** Turn pump on.
- 5** Watch the site glass at the top backside of the filter.
Allow pump to run until the water clears (approximately 1-5 minutes).
- 6** Turn pump off.
- 7** Press down on handle on top of filter and rotate clockwise to Rinse position.
- 8** Turn pump on.
- 9** Allow pump to run until water in site glass is clear.
(Approximately 30 seconds to 1 ½ minutes)
- 10** Turn pump off.
- 11** Press down handle and turn to Filter position.
- 12** Turn pump on.

This is just a guide. Pools and equipment vary and are not always maintained the same.

Find us on 

Retail Store is Located at:
4873 West Spencer Field Road
Pace, FL 32571

www.pacepoolandspa.com