

## HT-300 MIDI bank/program change list

Name	Bank	Patch
Acoustic Piano	0	0
Bright Piano	0	1
Clavinet	0	7
E Grand Piano	0	2
E Piano 1	0	4
E Piano 2	0	5
E Piano 3	24	4
E Piano 4	8	4
E Piano 5	8	5
E Piano 6	16	4
E Piano 7	16	5
Harpsichord 1	0	6
Cpld Harpsichord	8	6
Honky-tonk 1	0	3
Carillon	9	14
Celesta	0	8
Church Bell	8	14
Dulcimer	0	15
Glockenspiel	0	9
Marimba 1	0	12
Music Box	0	10
Tinkle Bell	0	112
Tubular Bell	0	14
Vibraphone 1	0	11
Xylophone	0	13
Accordion	0	21
Accordion Tango	0	23
Harmonica	0	22
Organ Dbar F	2	16
Organ Dbar S	0	16
Organ Detuned 1	8	16
Organ Detuned 2	8	17
Organ Elec 1	32	16
Organ Elec 2	32	17
Organ Gospel F	4	16
Organ Gospel S	3	16
Organ Ped Dbar	40	16
Organ Ped Pipe 1	37	19
Organ Ped Pipe 2	38	19
Organ Ped Pipe 3	39	19
Organ Ped Pipe 4	40	19
Organ Ped Pipe 5	41	19
Organ Ped Pipe 6	42	19
Organ Ped Pipe 7	43	19
Organ Ped Pipe 8	44	19

Organ Perc	0	17
Organ Pipe 1	1	19
Organ Pipe 10	10	19
Organ Pipe 11	0	19
Organ Pipe 12	12	19
Organ Pipe 13	13	19
Organ Pipe 14	14	19
Organ Pipe 15	15	19
Organ Pipe 16	16	19
Organ Pipe 17	17	19
Organ Pipe 18	18	19
Organ Pipe 19	19	19
Organ Pipe 2	2	19
Organ Pipe 20	20	19
Organ Pipe 21	21	19
Organ Pipe 22	22	19
Organ Pipe 23	23	19
Organ Pipe 24	24	19
Organ Pipe 25	25	19
Organ Pipe 26	26	19
Organ Pipe 27	27	19
Organ Pipe 28	28	19
Organ Pipe 29	29	19
Organ Pipe 3	3	19
Organ Pipe 30	30	19
Organ Pipe 31	31	19
Organ Pipe 32	32	19
Organ Pipe 33	33	19
Organ Pipe 34	34	19
Organ Pipe 35	35	19
Organ Pipe 36	36	19
Organ Pipe 4	4	19
Organ Pipe 5	5	19
Organ Pipe 6	6	19
Organ Pipe 7	7	19
Organ Pipe 8	9	19
Organ Pipe 9	8	19
Organ Pop	16	16
Organ Reed	0	20
Organ Rock F	1	18
Organ Rock S	0	18
12 Str Guitar	8	25
Chorus Guitar	8	27
Clean Guitar	0	27
Distortion Guitar	0	30
Funk Guitar	8	28

Guitar Feedback	8	31
Guitar Harmonics	0	31
Hawaiian Guitar	8	26
Jazz Guitar	0	26
Mandolin	16	25
Muted Guitar	0	28
Nylon Guitar	0	24
Nylon Guitar 2	16	24
Overdrive Guitar	0	29
Steel Guitar	0	25
Ukulele	8	24
Acoustic Bass	0	32
Fingered Bass	0	33
Fretless Bass	0	35
Picked Bass	0	34
Rubber Bass	16	39
Slap Bass 1	0	36
Slap Bass 2	0	37
Synth Bass 1	0	38
Synth Bass 2	0	39
Synth Bass 3	8	38
Synth Bass 4	8	39
Cello	0	42
Contrabass	0	43
Harp	0	46
Pizzicato Strings	0	45
Timpani	0	47
Tremolo Strings	0	44
Viola	0	41
Violin	0	40
Choir Aahs	0	52
Orch Strings	0	48
Orchestra	8	48
Orchestra Hit	0	55
Slow Strings	0	49
Synth Strings 1	0	50
Synth Strings 2	0	51
Synth Strings 3	8	50
Synth Vox	0	54
Voice Oohs	0	53
Brass 1	0	61
Brass 2	8	61
Cornet	2	56
Euphonium	1	58
French Horn	0	60
Muted Trumpet	0	59
acca mamper	•	33

0 0 8 8 0	62 63 62 63 57
8 8 0	62 63
8	63
0	
-	57
0	
_	56
0	58
0	65
0	67
0	70
0	71
0	69
0	68
0	64
0	66
0	76
0	73
0	79
0	75
0	72
0	72 74
-	
0	74
0	74
	0 0 0 0 0 0 0 0 0

Charang	0	84
Chiffer Lead	0	83
Saw Synth	1	81
Saw Wave	0	81
Sine Wave	8	80
Solo Vox	0	85
Square Synth	1	80
Square Wave	0	80
Synth Calliope	0	82
Bowed Glass	0	92
Fantasia	0	88
Halo Pad	0	94
Metal Pad	0	93
Polysynth	0	90
Space Voice	0	91
Sweep Pad	0	95
Warm Pad	0	89
Atmosphere	0	99
Brightness	0	100
Crystal	0	98
Echo Drops	0	102
Echo Pan	2	102
Goblin	0	101
Ice Rain	0	96
Soundtrack	0	97

0	103
0	109
0	105
0	110
0	108
0	107
0	106
0	111
0	104
0	114
8	107
	0 0 0 0 0 0 0 0

DRUM SETS		
Brush Set	0	40
Dance Set	0	26
Electronic Set 1	0	24
Electronic Set 2	0	25
Jazz Set	0	32
Power Set	0	16
Room Set	0	8
Standard Set 1	0	0
Standard Set 2	0	1