

HOW TO MEASURE A SPA OR HOT TUB JET



Use these three measurements to narrow down the correct replacement jet insert.



1 FACE DIAMETER

MEASURE EDGE TO EDGE

Place a ruler or caliper across the widest part of the visible jet face. Measure straight through the center - not around the curve.



2 THREAD DIAMETER

MEASURE THE WIDEST THREADED AREA

Measure straight across the outside edges of the threaded area. Do not measure the smaller diffuser tip above it.



3 DIFFUSER LENGTH

MEASURE FROM TIP TO BACK OF FACE

Lay the jet on its side. Measure from the end of the diffuser to the rear surface of the face - keep the ruler parallel to the jet body.

BEFORE YOU ORDER

- Remove the jet insert from the spa before measuring.
- Use a digital caliper when possible; record inches and millimeters.
- Compare the back connection, tabs, threads, and diffuser shape - size alone is not enough.
- The dimensions shown in the photos are examples only.