


Press **Counter** on the copiers home screen



The meter readings are now displayed on screen. The ones we need are the **Black and Colour on the far left** as highlighted below.

