

Quickstart Guide

ChickenMaster PRO

On initial power up the following steps must be performed !

1 SET the current DATE




Then PRESS
MENU/OK
Button

SCROLLS UP (Hold for fast scroll) ENTERS MENU MODE & ACCEPTS CHANGES MADE
SCROLLS LEFT SCROLLS RIGHT ABORTS CHANGES MADE & GOES BACK UP A LEVEL IN THE MENU STRUCTURE
SCROLLS DOWN (Hold for fast scroll) ESCAPE

2 SET Daylight Savings Time Adjustment



Then PRESS
MENU/OK
Button



Showing further options that are available below the first item.

3 SET the Local Time in 24 Hour format



Then PRESS
MENU/OK
Button

4 SET the UTC Time Zone (Refer to Section A)



Then PRESS
MENU/OK
Button

5 SET the LATITUDE (Refer to Google Maps)



Then PRESS
MENU/OK
Button

6



SET the LONGITUDE

Then PRESS
MENU/OK
Button

Using Google Map Apps (Android & iPhone)

1. Open the Google Maps app on your Phone or Computer 2. Tap and hold your desired location on the map 3. You should see "Dropped Pin" in the tab at the bottom of the screen. If an address is displayed, tap and hold a nearby location until "Dropped Pin" is displayed 3. Scroll down to see the displayed location coordinates.

Note: Positive Values = North Latitude or East Longitude, Negative Values =South Latitude or West longitude

7 You are now at the MAIN HOME SCREEN



A

UTC Time Zones for Australian States & Territories

Western Australia (WA)	+08:00
South Australia (SA)	+09:30
Northern Territory (NT)	+09:30
New South Wales (NSW)	+10:00
Victoria (VIC)	+10:00
Tasmania (TAS)	+10:00
Australian Capital Territory (ACT)	+10:00
Queensland (QLD)	+10:00
Lord Howe Island	+10:30

Resource: www.timeanddate.com

Your ChickenMaster PRO Initial Setup is now complete.



To obtain your Installer Password and to Register your ChickenMaster PRO Warranty SCAN the QR Code. If asked, enter Password 2022 to gain access to the Registration Page.

FarmTronics AUSTRALIA

www.farmtronics.com.au 4/1 Cannery Court, TYABB. Victoria. 3913 Phone: 0411 479 411