

### *StormMaster Shake*



- 50 Year Shingle
- Lifetime Warranty = 50 Years~ Prorated after 20 years (After 20 years, the warranty is prorated, with coverage decreasing over time.)
- 20 Year Non-Prorated Warranty (Fully Covered for 20 years, covering labor and material costs for manufacture defects.)
- 15 Year Wind Warranty ~ (150 mph wind coverage)
- Lifetime Scotchgard Algae Resistant Warranty

### *Pinnacle Impact*



- 30 Year Shingle
- Lifetime Warranty = 50 Years~ Prorated after 15 years (After 15 years, the warranty is prorated, with coverage decreasing over time.)
- 15 Year Non-Prorated Warranty (Fully Covered for 15 years, covering labor and material costs for manufacture defects.)
- 15 Year Wind Warranty ~ (130 mph wind coverage)
- Lifetime Scotchgard Algae Resistant Warranty

### *Pinnacle Pristine*



- 30 Year Shingle
- Lifetime Warranty = 50 Years~ Prorated after 15 years (After 15 years, the warranty is prorated, with coverage decreasing over time.)
- 15 Year Non-Prorated Warranty (Fully Covered for 15 years, covering labor and material costs for manufacture defects.)
- 15 Year Wind Warranty ~ (130 mph wind coverage)
- Lifetime Scotchgard Algae Resistant Warranty

### *Pinnacle Sun*



- 30 Year Shingle
- Lifetime Warranty = 50 Years~ Prorated after 15 years (After 15 years, the warranty is prorated, with coverage decreasing over time.)
- 15 Year Non-Prorated Warranty (Fully Covered for 15 years, covering labor and material costs for manufacture defects.)
- 15 Year Wind Warranty ~ (130 mph wind coverage)
- 10 Year Algae Resistant Warranty

### *ProLam*



- 20 Year Shingle
- Lifetime Warranty = 50 Years~ Prorated after 10 years (After 10 years, the warranty is prorated, with coverage decreasing over time.)
- 10 Year Non-Prorated Warranty (Manufacturing defects that lead to leaks or premature failure. Repair or replacement of the defective shingles only. does not include labor, tear-off, or disposal costs during the prorated period)
- 15 Year Wind Warranty ~ (130 mph wind coverage)
- 10 Year Algae Resistant Warranty

### NOTE:

- Application for the warranty must be submitted by the homeowner or EXT Enhancements. Once approved you will receive an official warranty certificate.
- In order for any Atlas warranty to apply, ALL Atlas products must be used on the residence. (Shingle, Starter, Cap, Synthetic, Ice and Water Shield, Etc.)

