

HYDRASTX® Gen 1 / Gen 2 Identification Guide				
Generation 1		Description	Generation 2	
GW Part #	HB Part #		GW Part #	HB Part #
i08550	OP-2HYDRASTX G1	2 Spool System	i10000	OP-2STX-G2
i08551	OP-3HYDRASTX G1	3 Spool System	i10001	OP-3STX-G2
i08552	OP-STX-REMOTE G1	Rf Remote	i10002	OP-STX-G2 REMOTE
i08300	EL-STX-CTRL G1	In-Cab Controller	i09975	EL-STX-G2 CTRL
i08477	No Part #	Standard Dongle	i09976	No Part #
i08309	No Part #	RF Dongle	i09951	No Part #

***\*\*Use GW part number located on silver tag of in-cab controller, RF Remote, and both dongles to determine if system is Gen 1 or Gen 2.***



#### NOTES:

- Dongle Connection is different on a Gen 2 system – the connections are **not** interchangeable.
- Main Harness connection at bottom of in-cab controller is the same and is interchangeable.
- Servos, servo mount, servo linkages, and harnesses are all the same and interchangeable.
- If replacing a G1 in-cab controller with RF Remote but customer wants to upgrade to G2 in-cab controller – Customer **must** also purchase a Gen 2 RF Dongle pre-programmed to their existing RF Remote's unique RFID Code. Their existing Remote will then communicate with the new RF Dongle. *The RFID Code can be found on the silver tag on the RF Dongle and on the back of the RF Remote.*
- If replacing a G1 in-cab controller without RF Remote – customer can simply purchase a G2 in-cab controller and plug into the existing harness.
- If replacing a G1 RF Remote – **must** send G1 remote for replacement unless customer wants to purchase G2 In-cab controller to upgrade.