



HF-1800 DRAWING OUTLINE

30-0300 HF-1800 GENERAL DIMENSIONS

30-0302 HF18-24 FINAL ASSEMBLY, HF-1800

30-1307 HF18-24 LID TO BODY, HF-1800, WDMT

30-1302 HF18-21 BODY, HF-1800, WDMT

30-2300	HF18-3	FRONT, BREAK DETAIL, HF-1800
30-2301	HF18-4	BACK, BREAK DETAIL, HF-1800
30-2302	HF18-2D	END, DISCHARGE, HF-1800
30-2303	HF18-2M	END, MOTOR, HF-1800
30-2208	HF12-52	MOUNTING TAB, HYDRA-FEEDER
30-1202	HF12-22	LIFT BRACKET, HYDRA-FEEDER
30-1203	HF12-53	DISCHARGE TUBE, HYDRA-FEEDER
30-1304	HF18-10	FOOT, HF-1800
30-1204	HF12-54	MOTOR MOUNT PLATE, HYDRA-FEEDER, WDMT
30-2209	HF12-16	PLATE, MOTOR MOUNT, LASER CUT, HYDRA-FEEDER
30-1305	HF18-15F/R	GUSSET, FRONT & REAR, HF-1800

30-1303 HF18-12 LID, HF-1800, WDMT

30-2304	HF18-12	LID, LAYOUT, HF-1800
30-2207	HF12-51	SHOCK MOUNT, LID, HYDRA-FEEDER/WB
30-1300	HF18-11	HANDLE, HF-1800, WDMT
30-2306	HF18-21	HANDLE, HF-1800, LASER

30-1220 HF12-59 AUGER SPOUT, HYDRA-FEEDER, ASSY.

30-1218 HF12-12 SPOUT, HYDRA-FEEDER, WDMT

30-2205	HF12-11	SPOUT, CUT & BREAK, HYDRA-FEEDER
---------	---------	----------------------------------

HF-1800 DRAWING OUTLINE

30-1219	HF12-58	MOTOR/AUGER MOUNT, HYDRA-FEEDER
30-1209	HF12-47	AUGER ASSEMBLY, HYDRA-FEEDER
30-1208	HF12-32	AUGER DETAILS, HYDRA-FEEDER
30-2211	HF12-26	AUGER HUB
30-2212	SP .853x.44x.28	SPACER, .853x.44x.28, HYDRA-FEEDER
30-2213	HF12-49	SENSOR GUARD, HYDRA-FEEDER
30-1306	HF18-23	AUGER BAFFLE MOUNT, HF-1800
30-1301	HF18-14	AUGER SHIELD, HF-1800
30-2305	HF18-20	AUGER SHIELD, BREAK, HF-1800