Tube Hanger Installation Instructions for PTF Fans

CONTENTS

The Tube Hanger Package consists of 10 Hanger Sets. Each Hanger Set has a Barrel, an Insert, and a Clip. See Figure 1. The optional Tube Support Wire Package consists of the cable, a turnbuckle, and two cable clamps.

INSTALLATION

Place the Insert inside the tube. Position the Insert at the intended location (see Table 1). Hold the Insert firmly and slide the Barrel over the Insert (and tubing) until both ends of the Insert protrude from the ends of the Barrel as shown in Figure 2. Install the metal Clip through the holes in the Barrel (see Figure 3), being careful not to puncture the tubing, and attach the Clip to the support cable. Figure 4 shows the completed hanger assembly.

Tube Diameter	Hanger Spacing
12"	5 Ft.
19"	5 Ft.
25"	4 Ft.
30"	4 Ft.

Table 1 — Recommended Hanger Spacing




Figure 4 — Assembled Hanger Kit




Figure 1 — Tube Hanger Kit




Figure 2 — Insert/Barrel Assembly




Figure 3 — Clip/Barrel Assembly



AMERICAN COOLAIR CORPORATION

PO BOX 2300, JACKSONVILLE, FL 32203

Phone – (904) 389-3646 Fax – (904) 387-3449 E-Mail – agfans@coolair.com Internet – www.coolair.com