



902 Hwy 246, Sabetha, KS 66534

1-800-530-5624

Wireless Pendant External Antenna Installation Guide

These instructions will allow you the ability to use an external antenna in order to extend the range of your wireless pendant remote.

1. Locate the wireless control box and remove the cover. Cut the bare looped wire indicated in the picture.
2. Drill a 13/32" hole in the cover of the control box close to the external antenna connector.
3. Feed the external antenna cable connector through the drilled hole in the cover and connect the external antenna to the connector shown in the circle.
4. Reinstall the cover for the wireless control box and route the external wireless antenna to the desired location.
5. Fill the drilled hole in the cover with silicone to seal the cable.

