




HOME

ATTACHMENTS

ALPHABETICAL INDEX

VAC01, VAC016.....11
BVAC52, BVAC62.....11
BVAC04 Barrel Collector.....13
BVACBX - Mounting.....15
BVACBX - Box Assy.....17

VAC01, VAC016, BVAC52, BVAC62 VACUUM BLOWER



INDEX


VAC01, VAC016, BVAC52, BVAC62 VACUUM BLOWER

REF.	PART NO.	DESCRIPTION	REQ'D
1	C46251	HOUSING - blower (for 42", 52" Deck) (VAC01).....	1
1	C46252	HOUSING - blower (for 62"Deck)(VAC016).....	1
1	C46775	HOUSING - blower (for 52SD Deck) (BVAC52)	1
1	C46776	HOUSING - blower (for 62SD Deck) (BVAC62)	1
2	C46258	BLADES - blower	1
3	C46308	LID - blower (includes decals).....	1
4	C46325	DECAL - "DANGER"	1
5	C46264	DECAL - "WARNING"	1
6	C28277	FLANGE - bearing (early production)	4
7	C28817	BEARING - 3/4" with lock collar (early production)	2
8	C45919	BEARING - flange (current production)	2
	219-37	FITTING - grease 1/4" - 28 x 450.....	1
9	C44100	FITTING - grease 1/4" -28 x 1-5/8" (in lower bearing)	1
10	195-545	WASHER - shim .135"	2
11	C28226	WASHER - shim .036"	1
12	C38405	PULLEY - drive	1
13	83-55	SCREW - set 5/16" - 18 x 5/16"	2
14	C29581	KEY - 3/16" square x 1"	1
15	113-132	BOLT - 1/4" - 20 x 1-3/4"	1
16	195-102	WASHER - 5/16" x 3/4"	5
17	192-19	LOCKWASHER - 1/4"	3
18	129-101	NUT - 1/4"-20	3
19	113-3	BOLT - 1/4" - 20 x 3/4"	2
20	111-203	BOLT - 5/16" - 18 x 1" carriage	2
21	131-176	NUT - 5/16" - 18 lock.....	4
22	113-103	BOLT - 5/16"-18 x 1"	2
23	C38398	PLATE - bearing.....	1
24	192-20	LOCKWASHER - 5/16"	6
25	113-102	BOLT - 5/16" - 18 x 3/4"	6
26	C38864	PULLEY - idler	1
27	113-233	BOLT - 3/8" - 16 X 1-3/4"	1
28	195-103	WASHER-3/8"	2
29	131-1352	NUT - 3/8" flange lock	2
30	C45820	ARM - idler (includes bushing) (current production)	1
31	C16714	BUSHING - straight sleeve	1
32	C16745	BOLT - shoulder	1
33	195-533	WASHER - 1/2"	1
34	C38575	BRACKET - tightener, idler pulley (early production)	1
35	NSS	ARM - idler (early production) (use C45820, C16745, 195-533, 131-1352).....	1
36	C38401	BUSHING - idler arm, flanged.....	1
37	C38408	SPRING - idler arm	1
38	C46298	GUARD - belt	1
39	187-1036	SCREW - 1/4" - 20 x 1/2" tapping	2
40	C37837	SPRING - return.....	1
41	C37707	BELT - A39.38" 52" Deck (all except 2000 series) (VAC01, BVAC52).....	1
41	C46302	BELT - A45.5" 62" Deck (all except 2000 series) (VAC016, BVAC62).....	1
41	C37995	BELT - A38" (VAC01) 52" Deck (2000 series)	1
41	C38407	BELT - A44" (VAC016) 62" Deck (2000 series).....	1
41	C37762	BELT - A35" (VAC01) 42" Deck	1
41	C38406	BELT - A34" (VAC01) (use with 42T12 Deck) (12.5 hp tractors).....	1
42	C46301 *	PULLEY - mower 6.5" (VAC016) 62" Deck.....	1
42	C46300 *	PULLEY - mower 5.5" (VAC01) 52" Deck.....	1
	C39204	COVER - deck blower pulley (BVAC52)	1
	C41392	COVER - deck blower pulley (BVAC62)	1

* Special Pulleys Used on units with AGRI-FAB or Chain drive

MODEL FCBC BARREL COLLECTOR


BARREL COLLECTOR



INDEX**MODEL FCBC BARREL COLLECTOR****BARREL COLLECTOR**

REF.	PART NO.	DESCRIPTION	REQ'D
1	C38584	BARREL	1
2	C38411	MOUNT - barrel.....	1
3	C38412	HANDLE.....	1
4	C38413	BRACKET - barrel mount.....	1
5	C37922	PIN - "fas-tatch"	2
6	C37581	WASHER - body mount	2
7	C38414	LID - barrel	1
8	C38415	DEFLECTOR	1
9	C38416	SCREEN	1
10	C38417	MOUNT-lid	1
11	C38404	SPRING.....	1
12	C38418	CLAMP-hose.....	2
13	C38419	HOSE	1

BVACBX MOUNTING FRAME AND TUBE





INDEX

BVACBX MOUNTING FRAME AND TUBE

REF.	PART NO.	DESCRIPTION	REQ'D
1	C46107	RAIL - L.H. VACBX (shown)	1
1	C46183	RAIL - L.H. VACBXD.....	1
2	C46108	RAIL - R.H. VACBX (shown).....	1
2	C46184	RAIL - R.H.VACBXD	1
3	C46110	CHANNEL - rear	1
4	C46111	HINGE - box	1
5	C46114	LATCH - box	1
6	C26020	GRIP - handle	1
7	C46122	ROD - hinge	1
8	C46156	COUPLING - tube	1
9	C46736	ARM - coupling mounting.....	1
10	C38419	TUBE.....	1
11	C46164	PLATE - stiffener.....	1
12	113-104	BOLT - 5/16"-18 x 1-1/4"	2
13	113-102	BOLT - 5/16"-18 x 3/4"	8
14	192-20	LOCKWASHER - 5/16"	2
15	192-103	WASHER - 0.375"	6
16	131-C2	NUT - 5/16" - 18 flangelock	12
17	195-533	WASHER - 1/2"	4
18	132-310	PIN - cotter 1/8" x 1"	2
19	111-132	BOLT - 5/16" - 18 x 3/4" carriage	4
20	187-1036	SCREW - 1/4" - 20 x 1" (not shown) replace fender screws.....	2
21	C38434	SPRING - latch.....	1
22	C46174	ANCHOR - latch.....	2
23	C46176	ANCHOR - pawl	1
24	C46380	PAWL - latch	1
25	175-454	SCREW - 1/4" - 20 x 3/8"	7
26	131-1351	NUT - 1/4" - 20 flange lock.....	1
27	195-104	WASHER - .406"	5
28	C46359	CLAMP - hose 6" (includes knob)	2
	C46360	KNOB - clamp	2
29	129-103	NUT - 3/8" - 16	4
	111-371	BOLT - 3/8" - 16 x 1" carriage	2
31	192-21	LOCKWASHER - 3/8"	4
32	131-207	BOLT - 3/8" - 16 x 1"	2

BVACBX BOX ASSEMBLY



INDEX

BVACBX BOX ASSEMBLY

REF.	PART NO.	DESCRIPTION	REQ'D
1	C46292	ROD - door release L.H. (shown)	1
1	C46124	ROD - door release R.H.....	1
2	213-41	CLEVIS - 3/8"	2
3	129-163	NUT - 3/8"-24	2
4	C46125	DOOR - rear	1
5	C46131	PANEL - top	1
6	C46134	SHROUD - exhaust.....	1
7	C46135	DEFLECTOR - exhaust.....	1
8	C46136	INDICATOR - airflow.....	1
9	C46139	PANEL - side L.H	1
10	C46140	PANEL - side R.H.....	1
11	C46146	PANEL-front	1
12	C46268	PANEL - bottom	1
13	C46180	HANDLE - box.....	1
14	C46009	GRIP - handle	1
15	141-54	PIN - clevis 3/8" x 1"	2
16	132-321	PIN - cotter 3/32" x 1"	2
17	195-2067	WASHER - 1/2"	2
18	138-92	PIN - roll 3/16" x 3/4"	2
19	C46168	BRACKET - door hinge	2
20	175-413	SCREW - 5/16" - 18 x 3/4"	2
21	131-C2	NUT - 5/16" - 18 flange lock.....	26
22	C16573	SPACER.....	2
23	113-209	BOLT - 3/8"-16 x 1-1/2"	2
24	195-525	WASHER - 3/8"	4
25	131-1352	NUT - 3/8" - 16 flange lock	2
26	C46171	BRACKET - box hinge	2
27	111-132	BOLT - 5/16" - 18 x 3/4" carriage	8
28	C46169	BRACKET - corner.....	2
29	175-454	SCREW - 1/4" - 20 x 3/8"	28
30	175-405	SCREW - 1/4" -20 x 1/2"	8
31	131-1351	NUT - 1/4" - 20 flange lock	8
32	121-21	BOLT - 1/4" - 20 x 1/2" flange lock.....	7
33	192-19	LOCKWASHER - 1/4"	7
34	129-101	NUT - 1/4" - 20	7
35	C46282	DECAL - "WARNING" flying objects	1
36	C46283	DECAL - "WARNING" stand clear	1