

The Gate Wheel Making Light work of Heavy gates

PATENT PENDING

Add the Gate Wheel to your exisiting steel gate for an easy opening!

"Perfect, no more dragging that big heavy gate! ...and it was quick to add too!"

The Gate Wheel is low maintenance and ideally suited for your home, farms, rural properties and businesses. Adding the Gate wheel will help reduce any potential OH&S issues for the workplace or home to make light work of opening heavy steel gates.



How many Gate Wheels will you need?

To order phone 1800 062 723 www.quikfence.com.au 449 East Street, Warwick QLD 4370






The Gate Wheel

MAKING LIGHT WORK OF HEAVY GATES

Assembly instructions



"Perfect, no more dragging that big heavy gate!

space to fit the wheel. Allow 200mm in height and 185mm in width as a minimum space for the wheel to move freely. 2. Place axle brackets over bottom rail of the gate. over the axle bracket.

1. Prepare the gate, add to an existing mesh gate, cut a

- 3. Place both halves of the wheel
- 4. Place all bolts through the four outer holes and secure the two halves together tightly.
- 5. Place the remaining two bolts through the axle bracket and wheel halves and tighten.
- 6. Fix brackets either side of the wheel on the gate to keep the wheel in place with tek screws supplied.

Distributed by

Australian made & manufactured by

