

INSTALLATION MANUAL

IP20

50000

CRI ≥ 80

RoHS

CE

VR213 RECESSED DOWNLIGHT








VR2138W
8W
220-240VAC

VR21324W
24W
220-240VAC

VR21310W
10W
220-240VAC

VR21336W
36W
220-240VAC

VR21316W
16W
220-240VAC



- Always disconnect the power supply before installing or performing any maintenance operations.
- Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
- These luminaires are widely used in commercial lighting, home decoration lighting, art gallery and museums.
- Only can be touched after 3 minutes later when power off, so as to avoid burns.
- Dismantling and refit are forbidden
- Installation on inflammables is forbidden.

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.