

Hot Farm

Weight classes –13,000lbs (No Open/Super Farm Tractors Allowed)

Class Rules:

- No speed or Rpm limit
- Stock appearing block
- Max turbo size - 3x3
- No tire size limit
- One fuel only
- OEM head and manifolds
- No V or double cut tires

Required Safety Equipment: (10 mph speed limit - if you do not have ALL required safety equipment)

- Steel flywheel, air shut off- need to disconnect at the rear of the tractor and hook to the sled
- Rops with seatbelt, wheelie bars, fire extinguisher
- Electric or no cooling fan
- Any type of safety equipment is recommended
- Dead Man Throttle

General Rules:

1. The driver must be present at the Driver's Meeting.
2. Any driver under 18 must have a parent present and a sign waiver.
3. Tractor may be 100 pounds max over posted class weight with the driver.
4. No pressurized fuel, nitrous oxide or other oxidizing agents allowed.
5. All engine radiator fans must be properly shrouded. All clutches, pressure plates, fly wheels and drive train components must have a 360 degree shroud of 3/16 inch or greater metal material.
6. Minimum drawbar length 18 inches from center of rear axle to point of hook, and may not pull from two or three-point hitching mechanisms.
7. The drawbar is to be stationary in all directions, and not to exceed 20" from top of drawbar.
8. No front weight frame or weights may extend more than 11' from the center of the rear axle.
9. All weights must be safely secured to the tractor; Rear weight must not interfere with hooking to the sled. If anything falls off during your pull, you will be disqualified.
10. Just before pulling, the puller will be weighed and must be on weight and move directly to staging.
11. Pullers must operate in a safe manner at all times; Operators must remain seated during the pull with at least one hand on the steering wheel.
12. Must be in neutral when hooked and unhooked.
13. All pulls must start from a tight hitch – no jerking permitted.
14. The driver is allowed one restart before 100 feet.
15. Tractor and skid must remain within boundaries of the contest course during the pull, or disqualified.
16. Driver must stop immediately upon signal from judge; Pull is over when forward motion stops
17. Failure to allow inspection by judges will result in disqualification.
18. Promoters reserve the right to refuse any entry.
19. Contest to be governed by judges with all decisions final. Judges have the right to stop and disqualify any tractor or truck if it is not being operated in a manner as would be considered safe.