


# Mastercam Library Post Processors Install

Account creation and hasp linking are required to access the Tech Exchange. Please visit https://www.cad-cam.com/wp-content/uploads/2019/05/Mastercam.com-Account-Registration-and-Linking-Instructions.pdf if you have not completed these steps.

- 1. Go to www.mastercam.com Login on the top right corner, your information should already be saved in the window.
- 2. Select Communities on the top left in the screen then Tech Exchange from the drop down.








SALES • SERVICE • SUPPORT

3. Once in the Tech Exchange you can search for a specific post processor with keyword or by type from the Product list.

Keyword				
Keyword				
Product			Version	
Product			2021	~
Tags			*	
Filter by Tag				
□ Purchasable Posts Only?				
SEARCH CLEAR				
I■ NEED HELP?	1			
Sample Files Tool Libraries	Posts	Plugins	Mill Turn Environments	



SALES • SERVICE • SUPPORT

4. Once you have found the post you would like to download, click the red bar below the post processor. See below:



Robodrill\_Fanuc 5X MILL.pst This is a chargeable post.

Files included in package:

- Robodrill\_Fanuc 5X Mill.mcam-mmd
- Robodrill\_Fanuc 5X MILL.mcam-control
- Fanuc Robodrill 5X Mill Application Guide.pdf
- Robodrill\_Fanuc 5X MILL.pst

CNC Post Revision: 23.00

Machine Name: Robodrill\_Fanuc 5X MILL

Control Name: Fanuc 30i 31i 32i

Description: Fanuc 5 Axis Mill Post

File Type: Post Versions: 2021 Products: Mastercam for SOLIDWORKS, Mill Views: 5 Downloads: 6

Files available for download:



Double click the mcam-content file. Mastercam 2021 will launch and all related post processor file will be automatically saved in DE-FAULT location. Default folders listed below for reference.

#### **Mill Posts**

- .mcam-mmd and .mcam-control files to C:\Users\Public\Documents\shared Mcam2021\cnc machines> directory.
- .pst and .psb files to C:\Users\Public\Documents\shared Mcam2021shared\mill\posts> directory.

#### **Lathe Posts**

- .mcam-Imd and .mcam-control files to C:\Users\Public\Documents\shared Mcam2021\cnc\_machines> directory.
- .pst and .psb files to C:\Users\Public\Documents\shared Mcam2021shared\lathe\posts> directory.

#### **Router Posts**

- .mcam-rmd and .mcam-control files to C:\Users\Public\Documents\shared Mcam2021\cnc machines>
- .pst and .psb files to C:\Users\Public\Documents\shared Mcam2021hared\router\posts> directory.


#### Wire Posts



Corporate Office: 810 Lawrence Dr Suite# 220 2940 E La Cresta Avenue Orange County: Visit our WEB page: URL <a href="http://www.cad-cam.com">http://www.cad-cam.com</a> Newbury Park, CA. 91320-1449 Anaheim, CA 92806-1833

805.375.7676 714.333.9020 Fax 805.375.7678 Fax 714.333.9022

e-mail us at: sales@cad-cam.com




SALES • SERVICE • SUPPORT


.mcam-wmd and .mcam-control files to C:\Users\Public\Documents\shared Mcam2021\cnc\_machines>

.pst and .psb files to C:\Users\Public\Documents\shared Mcam2021shared\wire\posts> directory.


6. Once the post processor is installed you will need to add it to your machine drop down. Machine> Mill (or Lathe, Wire, Router)> Manage List>Highlight post > Add.







SALES • SERVICE • SUPPORT



7. Post Processor is now available for you to use.

Having issues? Contact us <a href="mailto:postmod@cad-cam.com">postmod@cad-cam.com</a>



810 Lawrence Dr Suite# 220 Corporate Office: Orange County:

2940 E La Cresta Avenue Visit our WEB page: URL <a href="http://www.cad-cam.com">http://www.cad-cam.com</a> Newbury Park, CA. 91320-1449 Anaheim, CA 92806-1833

805.375.7676 714.333.9020 Fax 805.375.7678 Fax 714.333.9022

e-mail us at: sales@cad-cam.com