



You can download the App from your Google Play store or Apple App store. Look for Transcendent DVR Viewer. Your Alamo Technician will help you with the initial set up on your smart device. This quick guide will cover the basic camera access and video footage review.

Open up the Transcendent App (figure A).




When App opens it will open the as how it was last closed. Here we will be covering the most common icons (figure B).



(B1)


The amount of numbers will represent the amount of channels/camera displayed. Example is an eight channels/camera DVR. The circle around the number represents the current camera display (figure B1)




(B2)

(B3)

You can display more cameras by pushing the four square icon (figure B2). This will open a selection window where you can choose the display amount (figure B3). After selecting from 1, 4, 8 or 16 the camera(s) will auto populate. A display of eight was selected on (figure C) as an example.



You can also manipulate the location of your cameras by pushing and dragging to a desired location (figure D). To remove a camera you can push and drag up towards the word live, as soon as you are above it will turn into a red tab with a trash can icon. Let go and this will complete the removal of the camera. You will also notice the number will no longer have a circle around it (example camera 8 figure E).



(D)


Note: Removing a camera is only removes it from the current display.



(E)




Remote Play back on App



To access remote play back locate the camera reel icon (figure F1).




Remote Playback will replace Live in top title (figure G). All cameras can be played back at the same time. Keep in mind that the more cameras the smaller the display will be. We recommend reviewing playback one camera at a time.




To begin search, push the camera list icon (figure G1) this will open a camera selection screen (figure G2).




Once you select a camera the camera number will have a circle (figure G2). Push the camera list icon again ( figure G1).




Below (figure G3), You will have a few options like pinch out to zoom on the timeline, filter by event type & calander scroll to select date. All times start at 00:00 hour. See next page for mor info.









Once the camera populates (figure H). The rewind, fast forward and pause icons are now selectable (figure H1). Also the camera will start at 00:00 and start playing automatically.



Timeline will have blue and yellow coloring. Blue represents continuous video and yellow represents motion event. (figure H2). To be more precise with the timeline you can pinch out to magnify the hours.



To change the date click on the date and time icon (figure H3). This will open a selectable window of previous dates. Scroll down to move the date.



Icon (figure H3) represents playback filtering. You can select how you playback, (Motion, event etc).



Select different camera to playback.




Snapshot icon takes picture of current displayed image.




Record icon push once to start recording. Push again to stop and save footage.



To access snapshots and video clips you just saved, click on the back arrow. Arrow is located on the left next to the title Remote Playback (figure I). This should take you back to the title Live (figure J).



Once your on the title Live, you'll need to locate the avatar icon (figure J). Push icon to open menu window (figure K).



Locate the file icon and push. This will open a new window. This is where you will find your snapshots and video clips (figure L).

