



Vitek OnCue Viewer Application Quick Guide

Please Note: The Alamo CCTV Technician will assist with original set up. A full user guide can be viewed at:

http://www.vitekctv.com/Manuals/VT-HDOC-Series-DVR_Manual.pdf

You can access the OnCue Hybrid DVR system through 3G/4G or WiFi connection.
Main Features Include: Live View, Full Screen, Multi-Screen Display (4 Channel Split),
and PTZ Control (if PTZ camera applies).




Click on the App from your smart device.



The following screen will load, followed by the main screen.




Your DVR name will be listed here. Select the DVR and click connect on the bottom left of the screen




Once connected, your DVR will display all cameras (4, 8, or 16 depending on DVR size).
Double click on any camera to view in full screen mode.

Press disconnect at the top right to exit.



Press the **Search/Play** button in the middle to review playback. On this tab, you will be able to select a day, hour (00-24), and minute (00-59) to search. It will display only one channel (camera). Swipe screen to change to a different channel.



In playback mode, there are several functions:

Back: Return to the previous page

<<: Reverse Play (speed can be selected x2, x4, x8, x16, x32, x64)

<: Reverse slow playback

||: Pause

>: Fast Forward slow playback

>>: Fast Forward (speed can be selected x2, x4, x8, x16, x32, x64)



Thank you for being a loyal Alamo customer!