




Set-Top Box




Jump to Channel Feature

While watching a currently airing program, you can jump to another channel by entering the channel number you wish to change to then pressing the "select" button on your remote when done entering the channel number.




For You Feature

This feature is "For You" if you prefer a poster view format instead of traditional channel guide look. For You gives you quick access to Channels You've Watched, Channels Popular in Your Area, Movies on Now, Movies On Soon, and Recent Recordings. To access For You from the Program Guide, press the Back button on the remote to open the Tab Bar, and select the For You option. Use your remote to navigate and select what you would like to watch or record.




Program Search Feature

You can use the Search Feature to find Live and Future programs. Go to Search in the Tab Bar. From here you can type in the name of a program by typing in the first few letters of a program. The results will be more specific if you type in more letters in the name of the program. Highlight a program and press OK on your remote. If it is a currently airing program, you can highlight Watch and press OK on your remote to view it. You also have the option to select record for adding this program to future recordings. See the Recording Your Program section of this guide for more information.



Restart TV/ Fast-forward/ Rewind

This feature lets you go back to the beginning of any currently-airing program that has the Restart Option. While watching live TV, press on the center button of the navigation key to open the program play bar. Use the ring direction buttons to highlight the Restart button. Press the center of the remote to select and restart the program. You can also use this play bar to rewind, fast-forward or even record the current program, as well as turn on closed captioning.



Quick Guide

During a live or recorded program pres the left arrow on the direction circle to pull down a menu list of your most recently watched channels.



On-Screen Guide Management


From the channel guide, Pressing the center of the navigation key on a highlighted program will open a program screen with detailed information about the remote. This screen will also display Watch, Record, and Search Features.

To watch, use your remote to highlight the Watch button and press the center of the navigation key on the remote.

To Record a program, highlight the record button and press in the center of the navigation key. See the Record Your Program section of this guide to learn more about recording programs.


Choose the Search feature if you want to see future dates and times that this program will air or programs that have been recorded or scheduled for recording.

You can also skip this menu by pressing the play button on your remote from the guide screen to go straight to watching your show.



Channel Guide Above

On-Screen Guide Management Below



Series Recording

Use the series rules to manage episodes of a series that you want recoded automatically. From the recordings tab, scroll down and select the series you want to edit. Press select on edit and it will open the menu to edit start and stop times, how many recordings to keep and the types you want to record.

