

ON SITE REFRIGERATION

WINTERHALTER PT-M

OPERATING INSTRUCTIONS

1. SWITCHING ON

1. Check water, detergent and granular salt levels.
2. Turn on the main power switch.
3. Press the On/Off button on the machine.
4. Wait until the display shows the machine is ready.



2. OPERATING THE DISHWASHER

1. Pre-rinse dishes to remove food.
2. Load the basket and place it inside.
3. Close the hood – select cycle and the system will start automatically.
4. Wait for the cycle to complete and remove the clean basket.



3. DAILY CLEANING

1. Press the drain down button for 3 seconds.
2. Wait for automatic drain.
3. Remove and rinse filter, strainer basket and wash arms.
4. Replace the filter, strainer basket and wash arms.
5. Wipe the interior and leave hood open overnight.

